

RUFFLE CASSIS BLACK | カシス ブラック <sup>白破</sup>



**165 03 090** 30cmサービングプレート D-30.3 H-2.7 **¥6,200** 



**165 03 001** 31cmプレート D-31 H-2.9 **¥5,500** 



**165 03 002** 28cmプレート D-28 H-2.7 **¥3,000** 



**165 03 003** 25.5cmプレート D-25.5 H-2.7 **¥2,600** 



**165 03 004** 23cmプレート D-23.1 H-2.4 **¥1,900** 



**165 03 005** 21cmプレート D-21 H-2.2 **¥1,500** 



**165 03 006** 19cmプレート D-19.1 H-2 **¥1,400** 



**165 03 007** 17.5cmプレート D-17.5 H-1.9 **¥1,100** 



**165 03 010** 26cmリムスープボウル D-26 H-3.7 **¥2,900** 



**165 03 011** 23cmリムスープボウル D-23.3 H-3.5 **¥2,000** 



**165 03 035** 13.5cmマルチボウル D-13.5 H-7.6 **¥1,600** 



**165 03 036** 12cmマルチボウル D-12 H-6.8 **¥1,400** 



**165 03 037** 11cmマルチボウル D-11 H-6.2 **¥1,300** 



165 03 052 165 0 コーヒーカップ コーヒー L-11.7 S-9.4 H-7 D-15. C-200cc ¥1,200 ¥900

165 03 055 コーヒーソーサー D-15.1 H-2.1 ¥900





**178 00 002** 27cmリムプレート D-27.4 H-2.9 **¥2,500** 



**178 00 003** 24.5cmリムプレート D-24.5 H-2.5 **¥1,600** 



**178 00 004** 23cmリムプレート D-23.6 H-2.2 **¥1,400** 



**178 00 005** 21cmリムプレート D-21.7 H-2.2 **¥1,200** 



**178 00 006** 19.5cmリムプレート D-19.5 H-2.1 **¥1,100** 



**178 00 007** 17.5cmリムプレート D-17.5 H-1.9 **¥850** 



**178 00 008** 16cmリムプレート D-16 H-1.8 **¥750** 



118 00 002 28cmプレート D-28.1 H-2.8 **¥2,500** 



118 00 004 23cmプレート D-23.5 H-2.5 **¥1,400** 



118 00 006 19cmプレート D-19.5 H-2.5 **¥1,100** 



118 00 007 18cmプレート D-18.1 H-2 **¥850** 



178 00 062 25cmスクエアープレート D-25 H-3 **¥4,100** 



178 00 063 23cmスクエアープレート D-23.3 H-2.8 **¥3,500** 



178 00 064 20cmスクエアープレート D-20 H-2.4 **¥2,600** 



178 00 043 31.5cmプラター L-31.5 S-22.8 H-4 **¥4,100** 



178 00 044 29cmプラター L-29 S-21.2 H-3.7 **¥3,500** 



178 00 045 26cmプラター L-26.1 S-19 H-3.5 **¥2,900** 



178 00 047 23cmプラター L-23 S-16.7 H-3.1 **¥2,000** 



178 00 023 25.5cmディープスープボウル D-25 H-5.4 **¥2,500** 



178 00 024 23.5cmディープスープボウル D-23.8 H-5.2 **¥1,800** 



178 00 010 27cmリムスープボウル D-27 H-4.6 **¥2,500** 



178 00 011 24cmリムスープボウル D-24.3 H-4.4 **¥2,100** 



178 00 140 16.5cmトロンバトールボウル 14.5cmトロンバトールボウル 12.5cmトロンバトールボウル



178 00 142



178 00 143 D-16.9 H-10.4 **¥2,500** D-14.7 H-8.9 **¥2,000** D-12.5 H-8 **¥1,600** 



178 00 051 カプチーノカップ L-12.5 S-10.4 H-7.7 C-230cc ¥1,100 178 00 055 兼用ソーサー D-15.1 H-2 **¥750** 



178 00 052 コーヒーカップ L-11.7 S-9.4 H-7.1 C-200cc ¥**1,000** 178 00 055 兼用ソーサー D-15.1 H-2 ¥750





127 00 002 27cmプレート D-27.3 H-2.4 ¥2,400



**127 00 003** 25cmプレート D-25 H-2.3 **¥2,200** 



**127 00 004** 23cmプレート D-23 H-2.2 **¥1,500** 



**127 00 005** 21cmプレート D-21.4 H-2 **¥1,300** 



**127 00 006** 19.5cmプレート D-19.5 H-1.9 **¥1,200** 



**127 00 007** 17.5cmプレート D-17.5 H-1.8 **¥950** 



127 00 008 15.5cmプレート D-15.7 H-1.8 ¥750



**127 00 071** 27cm盛皿 D-27.1 H-1.8 **¥3,300** 



**127 00 010** 24.5cmリムスープボウル D-24.7 H-4 **¥2,200** 



127 00 075 29cmリーフベーカー L-29 S-21.3 H-4.9 ¥3,800



**127 00 011** 23cmリムスープボウル D-23 H-3.7 **¥1,500** 



**127 00 034** 18cmリムボウル D-18.1 H-5.7 **¥1,900** 



127 00 060 31cm スクエアープレート D-31.2 H-2.9 ¥6,900

127 00 061 27cm スクエアープレート D-27.1 H-2.8 ¥4,300

127 00 062 24cm スクエアープレート D-24.3 H-2.4 ¥3,600

127 00 064 21cm スクエアープレート D-21.2 H-2.2 ¥2,600

127 00 065 18cm スクエアープレート D-18.2 H-2.1 **¥2,100** 

127 00 066 12 16cm 14 スクエアープレート スク D-16.1 H-1.8 D-1 ¥1,800 ¥1

127 00 067 14cm スクエアープレート D-14.2 H-1.6 ¥1,400



**127 00 080** 35cmオブロンプラター L-35 S-22 H-2.4 **¥5,800** 



**127 00 082** 31cmオブロンプラター L-31.1 S-19.6 H-2.2 **¥4,200** 



**127 00 084** 28.5cmオブロンプラター L-28.6 S-18 H-2.1 **¥3,500** 



**127 00 097** 3連菜 L-33.1 S-11.9 H-2.1 **¥3,300** 



**127 00 031** スクエアー4連菜 D-22.8 H-2.2 **¥3,800** 



**127 00 086** 12cmトールボウル D-12.2 H-8.8 **¥1,400** 



**127 00 087** 10.5cmトールボウル D-10.5 H-7.5 **¥950** 



**127 00 088** 8cmトールボウル D-8.3 H-6.1 **¥750** 



**127 00 050** スタックマグカップ L-11.1 S-8 H-8.8 C-285cc **¥1,100** 



**127 00 058** ジャンボ片手スープカップ L-15 S-11.9 H-6.9 C-390cc **¥1,400** 



**127 00 057** スタックコーヒーカップ L-10.3 S-7.7 H-6.9 C-185cc **¥850 127 00 055** 兼用ソーサー

D-15.2 H-2.2 ¥600



127 00 059 スタックスープカップ L-12.1 S-9.3 H-6.3 C-260cc ¥950 127 00 055 兼用ソーサー

D-15.2 H-2.2 ¥600



**127 00 052** コーヒーカップ L-11.4 S-9 H-6 C-185cc **¥850 127 00 055** 兼用ソーサー D-15.2 H-2.2 **¥600** 



127 00 056 片手スープカップ L-13.9 S-10.7 H-6.3 C-290cc ¥1,300 127 00 055 兼用ソーサー D-15.2 H-2.2 ¥600





123 00 001 31.5cmプレート D-31.5 H-3.1 ¥4,100



123 00 002 26cmプレート D-26 H-3 ¥2,300



123 00 003 24.5cmプレート D-24.5 H-2.9 ¥1,900



123 00 004 23cmプレート D-23.3 H-2.6 ¥1,300



**123 00 005** 21cmプレート D-21 H-2.5 **¥1,100** 



**123 00 006** 19.5cmプレート D-19.6 H-2.3 **¥950** 



123 00 007 17cmプレート D-17 H-2.1 ¥850



**123 00 008** 15cmプレート D-15.1 H-1.9 **¥700** 



123 00 030 27.5cmティアベーカー L-27.7 S-18.5 H-8.3 ¥4,200



123 00 031 23cmティアベーカー L-23.2 S-15.5 H-7 ¥3,300



**123 00 034** 19cmティアベーカー L-19 S-12.8 H-5.8 **¥2,400** 



123 00 091 35.5cmプラター L-35.8 S-23.5 H-4.5 ¥4,800



123 00 093 33.5cmプラター L-33.5 S-22.2 H-4.2 ¥4,200



**123 00 094** 31.5cmプラター L-31.5 S-20.9 H-3.9 **¥3,700** 



**123 00 023** 18.5cmボウル D-18.6 H-6.6 **¥2,100** 



**123 00 024** 16cmボウル D-16.1 H-5.7 **¥1,600** 



**123 00 025** 13.5cmボウル D-13.6 H-4.7 **¥1,100** 



**123 00 027** 11cmボウル D-11.1 H-3.8 **¥950** 



**123 00 029** 7cmミニボウル D-7 H-2.9 **¥650** 



**123 00 020** 22cm反ボウル L-22.1 S-13.6 H-7.8 **¥2,900** 



**123 00 021** 17.5cm反ボウル L-17.7 S-11 H-6.6 **¥2,200** 



**123 00 022** 12cm反ボウル L-12.4 S-7.7 H-4.5 **¥1,200** 



**123 00 064** 多用カップ D-9.4 H-7 C-200cc **¥750** 



**143 00 092** 7.5cmトールボウル D-7.5 H-5.4 **¥750** 



**123 00 065** 22cm浅オーブンパン L-22.3 S-19.2 H-4.4 **¥2,200** 



**123 00 066** 19.5cm浅オーブンパン L-19.5 S-16.6 H-3.8 **¥1,900** 



**123 00 051** カプチーノカップ L-12.2 S-10.6 H-8.1 C-260cc **¥1,000 170 00 055** 兼用ソーサー D-15.2 H-2.2 **¥600** 




123 00 052 コーヒーカップ L-11.2 S-9.4 H-7.1 C-200cc ¥900 170 00 055 兼用ソーサー D-15.2 H-2.2 ¥600



123 00 058 エスプレッソカップ L-9.2 S-7.4 H-5.4 C-100cc ¥850 170 00 059 エスプレッソソーサー D-12.8 H-1.7 ¥550



123 00 063 クリーマー L-6.4 S-4.5 H-4 C-26cc ¥850











27.5cmクープⅢ D-27.8 H-3.2 **¥2,300** 

148 00 003 25.5cmクープⅢ D-25.8 H-3 **¥2,000** 

148 00 004 23cmクープⅢ D-23.3 H-2.8 **¥1,300** 



**148 00 005** 21cmクープ皿 D-21.1 H-2.6 **¥1,100** 



**148 00 006** 19cmクープ皿 D-19.3 H-2.5 **¥950** 



148 00 007 17.5cmクープ皿 D-17.8 H-2.2 ¥850



148 00 008 15.5cmクープ皿 D-15.8 H-2 **¥700** 



148 00 009 13.5cmクープ皿 D-13.7 H-2 **¥650** 













176 00 062 25cmスクエアープレート D-25.2 H-3.7 ¥3,300

176 00 063 22cmスクエアープレート D-22.1 H-3.2 ¥2,600

176 00 064 19.5cmスクエアープレート D-19.7 H-3 **¥2,200** 

176 00 065 17.5cmスクエアープレート D-17.5 H-2.8 ¥1,900

176 00 066 15.5cmスクエアープレート D-15.8 H-2.4 ¥1,600


176 00 067 13.5cmスクエアープレート D-13.5 H-2 ¥1,300



**141 00 045** 34.5cm角プラター L-34.6 S-23.4 H-4 **¥5,000** 



**141 00 046** 30.5cm角プラター L-30.5 S-20.6 H-3.7 **¥3,800** 



**141 00 047** 27cm角プラター L-27.4 S-18.4 H-3.1 **¥3,300** 




**142 00 048** 31.5cm細長角プラター L-31.6 S-10.1 H-2.1 **¥2,700** 



142 00 045 24cmカスター皿 L-23.8 S-13.9 H-1.4 **¥2,900** 



142 00 046 21cmカスター皿 L-21.2 S-11.8 H-1.3 **¥2,300** 



**142 00 049** 21.5cm細長カスター皿 L-21.8 S-8.8 H-1.4 **¥1,800** 



141 00 040 32.5cmティアプレート L-32.5 S-25.1 H-3.9 ¥4,200

141 00 041 28.5cmティアプレート L-28.6 S-22.1 H-3.3 ¥3,300

141 00 081 26.5cmティアプレート L-26.5 S-20.2 H-3.2 ¥2,900

141 00 042 24cmティアプレート L-24 S-18.5 H-3 ¥2,400

141 00 043 22cmティアプレート L-22.1 S-17.1 H-3 ¥2,200

**141 00 082** 19.5cmティアプレート L-19.5 S-15 H-2.8 **¥1,900** 

**141 00 044** 17cmティアプレート L-17 S-13.3 H-2.5 **¥1,600** 



**141 00 080** 36.5cmティアロングプレート L-36.7 S-15.1 H-3.4 **¥4,400** 



**141 00 083** 34cm中長ティアプレート L-34 S-21 H-3.6 **¥4,200** 



**141 00 085** 30cm中長ティアプレート D-30.1 S-18.5 H-3.6 **¥3,300** 



141 00 075 17cmティア小鉢 L-17.2 S-10.6 H-5.4 **¥1,600** 



141 00 076 15cmティア小鉢 L-15.4 S-9.4 H-4.9 ¥1,400



L-13.1 S-8.1 H-4.3 **¥1,100** 





141 00 037 15.5cmティア片口小鉢 L-15.5 S-10 H-5.2 ¥1,600



141 00 078 13.5cmティア片口小鉢 L-13.6 S-8.5 H-4.6 **¥1,400** 



141 00 079 11.5cmティア片口小鉢 L-11.6 S-7.3 H-4 **¥1,100** 



141 00 039 10cmティア片口小鉢 L-10.1 S-6.3 H-3.5 ¥950



141 00 026 25.5cm深皿 D-25.6 H-6.6 ¥4,400



141 00 027 22cm深皿 D-22.3 H-5.8 ¥3,300



141 00 028 20cm深皿 D-20.1 H-5 **¥2,600** 



141 00 071 17.5cmスクエアーボウル D-17.6 H-6.9 **¥2,300** 



141 00 072 15.5cmスクエアーボウル D-15.5 H-6 **¥1,900** 



141 00 073 14cmスクエアーボウル D-14 H-5.5 **¥1,500** 



141 00 011 23cm浅ボウル D-23.2 H-6.2 ¥2,600



141 00 014 17.5cm浅ボウル D-17.8 H-4.2 **¥1,200** 



141 00 015 13.5cm浅ボウル D-13.7 H-3.8 ¥850



142 00 083 からし入れ D-6.2 H-6.7 ¥900



199 00 088 ようじ立て D-3.7 W-4.2 H-5.1 ¥700



199 00 066 ソース醤油入れ L-7.6 S-5 H-11.5 C-115cc ¥1,900



199 00 000 カスター3点セット **¥5,300** (199 00 088·142 00 083·199 00 066·142 00 049)



141 00 052 コーヒーカップ L-10.8 S-8.1 H-6.9 C-185cc ¥850 170 00 055 兼用ソーサー D-15.2 H-2.2 ¥600



141 00 058 エスプレッソカップ L-9.1 S-6.8 H-6 C-100cc ¥750 170 00 059 エスプレッソソーサー D-12.8 H-1.7 ¥550



141 00 068 スティックシュガー& ナプキンスタンド大 L-10.3 S-8.2 H-8.9 **¥1,600** 



141 00 069 スティックシュガー& ナプキンスタンド小 L-8.7 S-6.5 H-8.2 **¥1,500** 



142 00 035 31cm3連皿 L-31 S-10.5 H-3.1 ¥2,700



142 00 036 27cm3連皿 L-27.3 S-9.2 H-2.8 ¥2,200



142 00 095 3菜皿 L-21.3 S-13.5 H-2.5 **¥2,400** 



142 00 030 23cm4菜皿 D-23.4 H-3.4 ¥3,800



142 00 031 21cm4菜皿 D-21.1 H-3.1 ¥3,300



142 00 032 18cm4菜皿 D-18.2 H-2.8 **¥2,400** 



148 00 096 丸型4連菜 L-35.6 S-9.8 H-2.3 ¥3,300



148 00 097 丸型3連菜 L-30.4 S-9.6 H-2.3 **¥2,200** 



147 00 098 トレー付丸型3連菜 L-30 S-22.5 H-2.3 ¥4,400



141 00 098 丸型珍味 D-7.4 H-4.8 ¥650



141 00 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥800



141 00 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥800



**141 00 096** 片口置きレンゲ L-12.6 S-5 H-6.7 **¥1,100** 



マットブラック

141 30 098 丸型珍味 D-7.4 H-4.8 ¥650



141 30 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥850



141 30 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥850

黒びぜん



141 31 098 丸型珍味 D-7.4 H-4.8 ¥700



141 31 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥900



141 31 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥900






141 40 098 丸型珍味 D-7.4 H-4.8 ¥850



141 40 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥950



141 40 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥950





141 31 003 25.5cmクープⅢ D-25.8 H-3 **¥2,100** 



141 31 004 23cmクープⅢ D-23.3 H-2.8 ¥1,400



141 31 005 21cmクープ皿 D-21.3 H-2.5 **¥1,200** 



141 31 006 19cmクープ皿 D-19.3 H-2.5 **¥1,100** 



141 31 007 17.5cmクープ皿 D-17.7 H-2.2 ¥950



141 31 008 15.5cmクープ皿 D-15.8 H-2 ¥850



141 31 009 13.5cmクープⅢ D-13.5 H-2 ¥700



141 31 062 25cmスクエアープレート D-25.2 H-3.7 **¥3,600** 



141 31 063 22cmスクエアープレート D-22.1 H-3.2 **¥2,900** 



141 31 064 19.5cmスクエアープレート D-19.7 H-3 **¥2,400** 



141 31 065 17.5cmスクエアープレート D-17.5 H-2.8 **¥2,100** 



141 31 066



141 31 067 15.5cmスクエアープレート 13.5cmスクエアープレート D-15.8 H-2.4 **¥1,800** D-13.5 H-2 **¥1,400** 



141 31 045 33.5cm角プラター L-33.6 S-22.8 H-3 **¥5,600** 



141 31 046 30.5cm角プラター L-30.5 S-20.6 H-3.7 **¥4,200** 



141 31 047 27cm角プラター L-27.4 S-18.4 H-3.1 **¥3,600** 



141 31 040 32.5cmティアプレート L-32.5 S-25.1 H-3.9 **¥4,500** 



141 31 041 28.5cmティアプレート L-28.6 S-22.1 H-3.3 **¥3,600** 



141 31 042 24cmティアプレート L-24 S-18.5 H-3 **¥2,600** 



141 31 044 17cmティアプレート L-17 S-13.3 H-2.5 ¥1,800



141 31 075 17cmティア小鉢 L-17.2 S-10.6 H-5.4 ¥1,800



141 31 076 15cmティア小鉢 L-15.4 S-9.4 H-5 ¥1,500



141 31 077 13cmティア小鉢 L-13.1 S-8 H-4.4 ¥1,100



141 31 071 17.5cmスクエアーボウル D-17.6 H-6.9 ¥2,600



141 31 072 15.5cmスクエアーボウル D-15.5 H-6 ¥2,100



141 31 073 14cmスクエアーボウル D-14 H-5.5 ¥1,600



142 31 017 22cmトロンバボウル D-22 H-8.5 **¥2,600** 



142 31 018 20.5cmトロンバボウル D-20.5 H-8.2 **¥2,200** 



142 31 024 18cmトロンバボウル D-18.2 H-7.5 **¥2,100** 



142 31 025 16cmトロンバボウル D-16.1 H-6.5 **¥1,500** 



142 31 026 13.5cmトロンバボウル D-13.5 H-5.5 ¥1,100



142 31 027 11cmトロンバボウル D-11.1 H-4.4 ¥950



142 31 040 16.5cm トロンバトールボウル D-16.5 H-10 ¥2,500



142 31 042 14.5cm トロンバトールボウル D-14.7 H-8.9 ¥1,900



142 31 043 12.5cm トロンバトールボウル D-12.5 H-8 ¥1,600



142 31 044 11.5cm トロンバトールボウル D-11.5 H-7.1 ¥1,200



142 31 064 19.5cmトロンバディッシュ D-19.8 H-4.7 ¥2,100



142 31 065 D-17.5 H-4.1 ¥1,400



142 31 066 17.5cmトロンバディッシュ 14cmトロンバディッシュ D-14.2 H-3.5 ¥1,100



142 31 095 3菜皿 L-21.3 S-13.5 H-2.5 ¥2,500



173 31 083 からし入れ D-6.2 H-6.7 ¥950



199 31 088 ようじ立て D-3.7 W-4.2 H-5.1 ¥750



199 31 066 ソース醤油入れ L-7.6 S-5 H-11.5 C-115cc ¥2,000



173 31 068 スティックシュガー& ナプキンスタンド大 L-10 S-8.2 H-8.9 ¥1.800



173 31 069 スティックシュガー& ナプキンスタンド小 L-8.7 S-6.5 H-8.2 ¥1.600



199 31 000 カスター3点セット **¥5,600** (199 31 088·173 31 083· 199 31 066 173 31 049)



WHITE PATH | ホワイト パス



**141 01 071** 17.5cmスクエアーボウル D-17.6 H-6.9 **¥2,600** 



**141 01 003** 25.5cmクープ皿 D-25.8 H-3 **¥2,300** 



**141 01 004** 23cmクープ皿 D-23.3 H-2.8 **¥1,500** 



**141 01 006** 19cmクープ皿 D-19.3 H-2.5 **¥1,200** 



**141 01 072** 15.5cmスクエアーボウル D-15.5 H-6 **¥2,200** 



**141 01 062** 25cmスクエアープレート D-25.2 H-3.7 **¥3,900** 



**141 01 064** 19.5cmスクエアープレート D-19.7 H-3 **¥2,600** 



**141 01 066** 15.5cmスクエアープレート D-15.8 H-2.4 **¥2,000** 

## WHITE SCRATCH | ホワイト スクラッチ



**141 13 071** 17.5cmスクエアーボウル D-17.6 H-6.9 **¥2,600** 



**141 13 003** 25.5cmクープ皿 D-25.8 H-3 **¥2,300** 



141 13 004 23cmクープ皿 D-23.3 H-2.8 ¥1,500



**141 13 006** 19cmクープ皿 D-19.3 H-2.5 **¥1,200** 



**141 13 072** 15.5cmスクエアーボウル D-15.5 H-6 **¥2,200** 



**141 13 062** 25cmスクエアープレート D-25.2 H-3.7 **¥3,900** 



**141 13 064** 19.5cmスクエアープレート D-19.7 H-3 **¥2,600** 



**141 13 066** 15.5cmスクエアープレート D-15.8 H-2.4 **¥2,000** 

## NIGHT PATH | ナイトパス



**141 33 071** 17.5cmスクエアーボウル D-17.6 H-6.9 **¥2,600** 



**141 33 003** 25.5cmクープ皿 D-25.8 H-3 **¥2,300** 



141 33 004 23cmクープ皿 D-23.3 H-2.8 ¥1,500



**141 33 006** 19cmクープ皿 D-19.3 H-2.5 **¥1,200** 



**141 33 072** 15.5cmスクエアーボウル D-15.5 H-6 **¥2,200** 



**141 33 062** 25cmスクエアープレート D-25.2 H-3.7 **¥3,900** 



**141 33 064** 19.5cmスクエアープレート D-19.7 H-3 **¥2,600** 



**141 33 066** 15.5cmスクエアープレート D-15.8 H-2.4 **¥2,000** 





128 00 001 32cmプレート D-32 H-3.1 ¥4,400



**128 00 002** 27.5cmプレート D-27.7 H-2.6 **¥2,500** 



**128 00 005** 23cmプレート D-23.3 H-2.2 **¥1,400** 



**128 00 006** 19cmプレート D-19.3 H-1.9 **¥1,100** 



**128 00 008** 16cmプレート D-16 H-1.5 **¥750** 



**120 00 002** ワイドロール27cmプレート D-27.2 H-2.9 **¥2,700** 



**120 00 004** ワイドロール23cmプレート D-23.2 H-2.4 **¥1,600** 



**120 00 005** ワイドロール20cmプレート D-20.2 H-2.1 **¥1,300** 



**120 00 006** ワイドロール17cmプレート D-17.2 H-1.7 **¥850** 



**120 00 023** ワイドロール25cmディープスープボウル D-24.8 H-6 **¥1,900** 



**120 00 011** ワイドロール24cmスープボウル D-23.8 H-4.1 **¥1,700** 



**128 00 015** 24cmスープ・パスタボウル D-24.1 H-5.8 **¥2,000** 



**128 00 012** 22cmスープ・パスタボウル D-22 H-5.5 **¥1,500** 



**128 00 024** 15cmボウル D-15 H-3.8 **¥1,000** 



128 00 093 30.5cmロングトレー L-30.6 S-11.8 H-2.2 ¥2,900



**120 00 027** 11cmホローボウル D-11 H-3.2 **¥1,300** 



120 00 028 9cmホローボウル D-9 H-2.6 ¥1,100



120 00 087 10cmオーバル ホローボウル L-10 S-7 H-4.4 ¥1,200



128 00 051 カプチーノカップ L-12.1 S-9.4 H-6.1 C-225cc ¥1,000 128 00 055 兼用ソーサー D-14 H-2.3 ¥650



128 00 052 コーヒーカップ L-11.8 S-8.8 H-5.7 C-180cc ¥900 128 00 055 兼用ソーサー D-14 H-2.3 ¥650





**194 00 010** 27cmリムスープボウル D-27 H-4.3 **¥2,600** 



**194 00 011** 23.5cmリムスープボウル D-23.5 H-3.7 **¥1,800** 



**194 00 012** 22cmリムスープボウル D-22 H-3.5 **¥1,500** 



**194 00 002** 27cmプレート D-27.1 H-3 **¥2,900** 



**194 00 003** 25.5cmプレート D-25.6 H-2.7 **¥2,200** 



**194 00 004** 23.5cmプレート D-23.5 H-2.5 **¥1,400** 



**194 00 005** 21.5cmプレート D-21.5 H-2.1 **¥1,300** 



**194 00 006** 19.5cmプレート D-19.5 H-1.9 **¥1,100** 



**194 00 061** 28cmスクエアープレート D-28.2 H-2.8 **¥4,400** 



194 00 062 26cmスクエアープレート D-26.2 H-2.8 ¥4,100



**194 00 063** 22cmスクエアープレート D-22.3 H-2.6 **¥3,200** 



194 00 064 20cmスクエアープレート D-20 H-2.5 **¥2,600** 



**194 00 065** 18cmスクエアープレート D-18.1 H-2.4 **¥2,200** 



**194 00 090** 34.5cm角プラター L-34.4 S-23.1 H-2.2 **¥5,600** 



**194 00 091** 32cm角プラター L-32 S-21.4 H-2 **¥4,600** 



**194 00 092** 29.5cm角プラター L-29.5 S-19.7 H-1.9 **¥4,100** 



194 00 161 27.5cm角皿 D-27.5 H-3.4 ¥4,400

**194 00 162** 26cm角皿 D-26.5 H-3.3 **¥4,200** 

**194 00 163** 23cm角皿 D-23.1 H-3.1 **¥3,300** 


194 00 164 20cm角皿 D-20.2 H-3 ¥2,600

194 00 165 18cm角皿 D-18 H-2.8 ¥2,100

194 00 166 15.5cm角皿 D-15.5 H-2.6 ¥1,800



**194 00 045** 33.5cmリムプラター L-33.7 S-22.5 H-3.3 **¥5,300** 



**194 00 046** 30cmリムプラター L-30.1 S-20.2 H-3.2 **¥4,200** 



**194 00 047** 28cmリムプラター L-28 S-18.5 H-2.9 **¥3,800** 



**194 00 026** 13cmスクエアーボウル D-13 H-3.5 **¥1,500** 



194 00 018 10.5cmスクエアー深皿 D-10.6 H-2.6 ¥1,100



194 00 019 9cmスクエアー深皿 D-9 H-2.4 ¥950



**194 00 020** 7.5cmスクエアー深皿 D-8 H-2 **¥850** 



194 00 075 13.5cm長角深皿 L-13.7 S-9 H-2.7 ¥1,300



194 00 076 12cm長角深皿 L-12.2 S-8.4 H-2.5 ¥1,100



194 00 077 10cm長角深皿 L-10.1 S-7 H-2.1 ¥950




194 00 052 コーヒーカップ L-10.7 S-8 H-6 C-170cc ¥950 139 00 055 兼用ソーサー D-15.2 H-2.2 ¥600









183 00 058 13.5cmソフトスクエアーボウル

D-13.5 H-5.9 **¥1,600** 

183 00 059 11cmソフトスクエアーボウル D-11 H-4.8 ¥1,200

183 00 096 10.5cm丸手付珍味 9cm丸手付珍味 L-10.5 S-8.1 H-3.7 L-9.3 S-7.2 H-3.3

183 00 097



183 00 098 183 00 099 10cm角手付珍味 8.5cm角手付珍味 L-10 S-7.5 H-5.5 L-8.7 S-6.5 H-4.8 ¥1,100





196 30 002 27.5cmリムプレート マット&シャイニーブラック D-27.7 H-2.5 **¥3,500** 

196 30 003 26cmリムプレート マット&シャイニーブラック D-26 H-2.4 **¥2,600** 

196 30 004 24cmリムプレート マット&シャイニーブラック D-24 H-2.2 **¥1,900** 

196 30 005 22cmリムプレート マット&シャイニーブラック

196 30 006 20cmリムプレート マット&シャイニーブラック

196 30 007 18cmリムプレート マット&シャイニーブラック D-22 H-2.1 **¥1,500** D-20 H-1.8 **¥1,400** D-18 H-1.6 **¥1,200** D-16 H-1.4 **¥950** 

196 30 008 16cmリムプレート マット&シャイニーブラック



183 30 002 27.5cmクープ皿 D-27.8 H-3.2 ¥2,700

183 30 003 25.5cmクープ皿 D-25.8 H-2.7 ¥2,300

183 30 004 23.5cmクープⅢ D-23.5 H-2.7 ¥1,500

183 30 005 21cmクープ皿 D-21.3 H-2.6 ¥1,300

183 30 006 19cmクープ皿 D-19.4 H-2.2 ¥1,200

183 30 008 15.5cmクープ皿 D-15.8 H-2.1 ¥950

183 30 009 13.5cmクープ皿 D-13.8 H-1.8 ¥850



183 30 061 27cmスクエアープレート D-27 H-3.4 ¥4,400

183 30 063 23cmスクエアープレート D-23.2 H-3.1 ¥3,500

183 30 064 19.5cmスクエアープレート D-19.7 H-2.4 ¥2,900

183 30 066 16cmスクエアープレート D-16 H-2.2 ¥2,100



27.5cm角皿 24cm角皿 D-27.8 H-2.8 D-24 H-1.9 ¥4,100 ¥5.000



20cm角皿 D-20.2 H-2.1 ¥3,000



196 30 023 26.5cmディープスープボウルマット&シャイニーブラック D-26.5 H-5 **¥2,900** 



196 30 024 24cmディープスープボウル マット&シャイニーブラック D-24.1 H-4.5 **¥2,100** 



183 30 010 29cmリムスープボウル マット&シャイニーブラック D-29 H-3.8 ¥5,300



183 30 011 27cmリムスープボウル マット&シャイニーブラック D-27 H-3.5 **¥3,500** 



183 30 012 25cmリムスープボウル マット&シャイニーブラック D-25 H-3 **¥2,900** 



183 30 076 31.5cm舟盛鉢 L-31.8 S-8.6 H-4.6 ¥3,700



L-31.5 S-7 H-4.5 ¥3,300



183 30 094 20cm細長盛鉢 L-20.1 S-6.8 H-3.7 ¥2,000



183 30 071 32cm盛鉢 L-32.3 S-15.2 H-4.3 ¥4,400



183 30 073 25.5cm盛鉢 L-25.5 S-12.2 H-3.5 ¥3,600



183 30 035 30.5cm3連皿 L-30.5 S-10 H-2 ¥3,200



¥2,500



183 30 017 22cm4角折込皿 D-22.3 H-3.4 ¥3,900



183 30 018 19cm4角折込皿 D-19 H-3.1 ¥3,200



183 30 086 12cmトールボウル D-12.3 H-9 ¥1,600



183 30 087 10.5cmトールボウル D-10.6 H-7.9 ¥1,100



183 30 088 8cmトールボウル D-8.2 H-6 **¥950** 



183 30 032 15.5cm多用井 D-15.6 H-8.3 **¥2,000** 



183 30 033 13.5cm多用井 D-13.5 H-7.1 **¥1,800** 



183 30 034 11cm多用井 D-11 H-5.8 **¥1,200** 



183 30 057 15.5cmソフトスクエアーボウル D-15.8 H-7 **¥2,400** 



183 30 058 13.5cmソフトスクエアーボウル D-13.5 H-5.9 ¥1,800



183 30 059 11cmソフトスクエアーボウル D-11 H-4.8 **¥1,300** 



183 30 096 10.5cm丸手付珍味 L-10.5 S-8.1 H-3.7 ¥1,100



183 30 097 9cm丸手付珍味 L-9.3 S-7.2 H-3.3 ¥1,000



183 30 098 10cm角手付珍味 L-10 S-7.5 H-5.5 ¥1,100



183 30 099 8.5cm角手付珍味 L-8.7 S-6.5 H-4.8 ¥1,000





**191 00 003** 25.5cmプレート D-25.6 H-2.7 **¥2,200** 

**191 00 004** 23.5cmプレート D-23.5 H-2.5 **¥1,400** 



191 00 005 21.5cmプレート D-21.5 H-2.1 ¥1,300

**191 00 006** 19.5cmプレート D-19.5 H-1.9 **¥1,100** 

**191 00 007** 17.5cmプレート D-17.5 H-1.7 **¥900** 



**191 00 061** 26cmスクエアープレート D-25.9 H-2.4 **¥4,100** 



191 00 062 24cmスクエアープレート D-24.1 H-2.3 ¥3,500



191 00 063 22cmスクエアープレート D-22 H-2.1 ¥3,200



**191 00 064** 20cmスクエアープレート D-20.2 H-1.9 **¥2,600** 



**191 00 010** 27cmリムスープボウル D-27 H-4.3 **¥2,600** 



**191 00 011** 24.5cmリムスープボウル D-24.6 H-3.7 **¥1,800** 



**191 00 012** 22cmリムスープボウル D-22 H-3.5 **¥1,500** 



**191 00 035** 13.5cmマルチボウル D-13.5 H-7.6 **¥1,300** 



**191 00 036** 12cmマルチボウル D-12 H-6.8 **¥1,100** 



**191 00 037** 11cmマルチボウル D-11 H-6.2 **¥950** 



**191 00 050** マグカップ L-11.5 S-8.6 H-9.8 C-330cc **¥1,100** 



191 00 052 コーヒーカップ L-10.8 S-8.3 H-6 C-170cc ¥1,000 191 00 055 コーヒーソーサー D-15.2 H-2.1 ¥700

REFLECTION MINT GREEN | ミント グリーン 白磁



**191 07 002** 27cmプレート D-27 H-3 **¥3,300** 





**191 07 003** 25.5cmプレート D-25.6 H-2.7 **¥2,500** 



**191 07 004** 23.5cmプレート D-23.5 H-2.5 **¥1,800** 



**191 07 005** 21.5cmプレート D-21.5 H-2.1 **¥1,500** 



**191 07 006** 19.5cmプレート D-19.5 H-1.9 **¥1,300** 



**191 07 007** 17.5cmプレート D-17.5 H-1.7 **¥1,000** 



**191 07 010** 27cmリムスープボウル D-27 H-4.8 **¥2,900** 



**191 07 011** 24.5cmリムスープボウル D-24.5 H-3.7 **¥2,100** 



**191 07 012** 22cmリムスープボウル D-22 H-3.5 **¥1,900** 



**191 07 035** 13.5cmマルチボウル D-13.6 H-7.6 **¥1,400** 



**191 07 036** 12cmマルチボウル D-12 H-6.8 **¥1,200** 



**191 07 037** 11cmマルチボウル D-11 H-6.2 **¥1,100** 



**191 07 050** マグカップ L-11.5 S-8.6 H-9.8 C-330cc **¥1,200** 



191 07 052 191 0 コーヒーカップ コーヒ-L-10.5 S-8.3 H-6.2 D-15.2 C-170cc ¥1,100 ¥850

**191 07 055** コーヒーソーサー D-15.2 H-2



REFLECTION ROSE PINK | ロゼピンク



191 09 002 27cmプレート D-27 H-3 **¥3,300** 



191 09 003 25.5cmプレート D-25.6 H-2.7 **¥2,500** 



191 09 004 23.5cmプレート D-23.5 H-2.5 ¥1,800



191 09 005 21.5cmプレート D-21.5 H-2.1 ¥1,500



191 09 006 19.5cmプレート D-19.5 H-1.9 ¥1,300



191 09 007 17.5cmプレート D-17.5 H-1.7 ¥1,000



191 09 010 27cmリムスープボウル D-27 H-4.8 **¥2,900** 



191 09 011 24.5cmリムスープボウル D-24.5 H-3.7 **¥2,100** 



191 09 012 22cmリムスープボウル D-22 H-3.5 **¥1,900** 



191 09 035 13.5cmマルチボウル D-13.6 H-7.6 ¥1,400



191 09 036 12cmマルチボウル D-12 H-6.8 ¥1,200



191 09 037 11cmマルチボウル D-11 H-6.2 ¥1,100



191 09 050 マグカップ L-11.5 S-8.6 H-9.8 C-330cc ¥1,200



191 09 052 コーヒーカップ コーヒーソーサ L-10.5 S-8.3 H-6.2 D-15.2 H-2 C-170cc **¥1,100 ¥850** 

191 09 055 コーヒーソーサ



**153 00 002** 26cmディナー皿 D-26 H-2.1 **¥2,500** 



153 00 004 23.5cm≷−トⅢ D-23.5 H-1.8 ¥1,400



153 00 005 20cmケーキ皿 D-20.1 H-1.6 ¥1,200



153 00 007 17cmパン皿 D-17.3 H-1.5 ¥750



**153 00 011** 23.5cmスープボウル D-23.5 H-4.2 **¥1,400** 



**153 00 013** 19cmクープボウル D-19.2 H-4.3 **¥1,200** 



153 00 034 16.5cmオートミール D-16.5 H-4.5 ¥1,000



**153 00 014** 14.5cmフルーツボウル D-14.5 H-3.7 **¥750** 



**153 00 054** 両手付ブイヨンカップ L-17 S-11.4 H-5.5 C-300cc **¥1,600** 



153 00 051 カプチーノカップ L-11.4 S-8.5 H-7.8 C-230cc ¥1,100 153 00 055 兼用ソーサー D-14.8 H-1.8 ¥700



153 00 052 コーヒーカップ L-10.6 S-7.8 H-6.8 C-170cc ¥1,000 153 00 055 兼用ソーサー D-14.8 H-1.8 ¥700



**153 00 053** ティーカップ L-12 S-9.2 H-5.3 C-180cc **¥1,000 153 00 055** 兼用ソーサー D-14.8 H-1.8 **¥700** 



153 00 058 デミタスカップ L-9.6 S-6.8 H-5.7 C-105cc ¥900 153 00 059 デミタスソーサー D-13 H-1.6 ¥600



149 00 000 31.5cmⅢ D-31.5 H-2.5 ¥5,800

149 00 001 D-28.1 H-2.3 ¥4,100

149 00 002 26cmⅢ D-26.2 H-2.5 ¥3,300

149 00 003 23cmⅢ D-23 H-2.3 ¥2,500

149 00 004 D-20.2 H-2.1 ¥2,100

149 00 005 17.5cmⅢ D-17.8 H-1.9 ¥1,900

149 00 006 149 00 007 15cmⅢ 13cmⅢ D-15.2 H-1.9 D-13 H-1.7 ¥1,600 ¥1,200



149 00 047 30cm中長角皿 L-30.3 S-15.1 H-1.9 ¥3,200



149 00 065 13.5cm取り皿 D-13.8 H-2 **¥1,300** 



149 00 066 12cm取り皿 D-12.2 H-1.7 **¥1,000** 



149 00 008 11cm取り皿 D-11.1 H-1.6 **¥850** D-8.9 H-1.2 **¥600** 



149 00 009 8.5cmⅢ



149 00 070 34.5cm細長角皿 L-34.9 S-11.2 H-1.8 ¥3,700



149 00 072 32cm細長角皿 L-32 S-11.2 H-1.8 ¥2,900



149 00 048 30cm細長角皿 L-30.4 S-10.1 H-1.7 ¥2,500



149 00 045 34cm長角皿 L-34 S-22.1 H-2.6 ¥5,000



149 00 046 30.5cm長角皿 L-30.7 S-20.4 H-2.3 ¥3,700



149 00 049 27.5cm長角皿 L-27.5 S-18.2 H-2 **¥3,300** 



149 00 050 25cm長角皿 L-25 S-17 H-1.8 ¥3,200

149 00 018

10.5cm深皿

D-10.5 H-2.1

149 00 099

7.5cm醤油皿

D-7.8 H-2.2

¥600

149 00 097

149 00 092 トレー付3連菜 L-26.5 S-22.5 H-3

149 00 032

149 00 063

L-22.2 S-11.1 H-1.7

2連皿

¥1,900

L-29.1 S-9.7 H-2.9

3連深皿

¥2,700


¥4,100

L-26.5 S-9.2 H-2.6

3連菜

¥2,300

¥900





¥2,100

149 00 086 28.5cm長角トレー 19.5cm長角トレー L-28.8 S-9.5 H-2.8 L-19.6 S-9.6 H-2.8 ¥1,800



149 00 052 コーヒーカップ L-10.9 S-8.1 H-7.2 C-180cc ¥950 149 00 055 コーヒーソーサ-D-12.3 H-1.6 ¥900



149 00 058 エスプレッソカップ L-8.7 S-6.5 H-5.7 C-100cc ¥850 149 00 059 エスプレッソソーサ D-11.1 H-1.6 ¥750







149 30 065 14cm取り皿 D-14.2 H-2 ¥1,300



**149 30 066** 12cm取り皿 D-12.3 H-1.8 **¥1,000** 



**149 30 008** 11cm取り皿 D-11.4 H-1.7 **¥850** 



**149 30 009** 8.5cmⅢ D-8.9 H-1.2 **¥550** 



**149 30 048** 31cm細長角皿 L-31 S-10.3 H-1.8 **¥2,400** 



**149 30 046** 31 cm長角皿 L-31.2 S-20.8 H-2.3 **¥3,500** 



**149 30 049** 28cm長角皿 L-28 S-18.6 H-2.1 **¥3,100** 



**149 30 047** 31.5cm中長角皿 L-31.7 S-15.4 H-2.3 **¥3,000** 



149 30 032 3連深皿 L-29.6 S-9.9 H-2.9 **¥2,600** 



149 30 033 2連深皿 L-19.5 S-9.7 H-2.8 ¥1,500



**149 30 031** 4連深皿 D-24.3 H-2.6 **¥3,700** 



149 30 011 23.5cm深皿 D-23.8 H-4.5 ¥3,100



149 30 013 18.5cm深皿 D-18.6 H-3.3 **¥2,100** 



149 30 014 15.5cm深皿 D-15.8 H-3.5 ¥1,800



**149 30 015** 13.5cm深皿 D-13.9 H-2.8 **¥1,500** 



 149 30 016
 149 30 018

 12cm深皿
 10.5cm深皿

 D-12.3 H-2.5
 D-10.9 H-2.2

 ¥1,100
 ¥850



**149 30 025** 15.5cmボウル D-15.7 H-4.8 **¥1,800** 



**149 30 026** 12.5cmボウル D-12.7 H-3.9 **¥1,300** 



**149 30 027** 9.5cmボウル D-9.7 H-2.9 **¥900** 



149 30 099 8cm醤油皿 D-8 H-2.3 ¥550



**149 30 036** 13cm深ボウル D-13.3 H-6.6 **¥1,800** 



149 30 037 10cm深ボウル D-10.4 H-4.8 ¥1,100



**149 30 039** 7cm深ボウル D-7.1 H-3.5 **¥650** 



149 30 052 コーヒーカップ L-11 S-8 H-7.1 C-180cc ¥900 149 30 055 コーヒーソーサー D-12.5 H-1.8 ¥850



149 30 058 エスプレッソカップ L-8.7 S-6.6 H-5.8 C-100cc ¥750 149 30 059 エスプレッソソーサー D-11.4 H-1.6 ¥700



SQUARE IVORY | アイボリー



149 20 004 20.5cmⅢ D-20.5 H-2.2 ¥2,000

**149 20 052** コーヒーカップ

¥900 149 20 055 コーヒーソーサー D-12.5 H-1.8 ¥850

L-11 S-8 H-7.1 C-180cc

149 20 006 15.5cmⅢ D-15.5 H-1.9 ¥1,500



149 20 008 11cm取り皿 D-11.4 H-1.7 ¥850



149 20 011 23.5cm深皿 D-23.8 H-4.5 ¥3,100



**149 20 013** 18.5cm深皿 D-18.6 H-3.3 **¥2,100** 




**149 20 015** 13.5cm深皿 D-13.9 H-2.8 **¥1,500** 



**149 20 046** 31cm長角皿 L-31.2 S-20.8 H-2.3 **¥3,500** 



SQUARE COBALT | コバルト





**149 86 008** 11cm取り皿 D-11.4 H-1.7 **¥850** 



149 86 011 23.5cm深皿 D-23.8 H-4.5 ¥3,100



149 86 013 18.5cm深皿 D-18.6 H-3.3 **¥2,100** 



149 86 015 13.5cm深皿 D-13.9 H-2.8 ¥1,500



**149 86 046** 31cm長角皿 L-31.2 S-20.8 H-2.3 **¥3,500** 









**125 00 001** 31.5cm丸皿 D-31.5 H-3.2 **¥4,100** 

125 00 002 26cm丸皿 D-26 H-2.8 ¥2,300 125 00 004 23cm丸皿 D-23 H-2.3 ¥1,300 125 00 005 21 cm丸皿 D-21 H-2.1 ¥1,200 125 00 006 19cm丸皿 D-19.2 H-2 ¥950 125 00 007 17cm丸皿 D-17.2 H-1.8 ¥850

125 00 008 15cm丸皿 D-15 H-1.7 **¥750** 



**177 00 061** 27cmソフトスクエアープレート D-27 H-4 **¥3,700** 



177 00 062 24cmソフトスクエアープレート D-24 H-3.6 ¥3,000



**177 00 064** 21cmソフトスクエアープレート D-21 H-3 **¥2,400** 



**177 00 065** 18cmソフトスクエアープレート D-18 H-2.6 **¥2,000** 



**177 00 066** 16cmソフトスクエアープレート D-16 H-2.4 **¥1,800** 



**177 00 045** 35cm角プラター L-35 S-24 H-3.2 **¥5,000** 



**177 00 046** 31cm角プラター L-31.3 S-21.7 H-3.1 **¥3,800** 



**177 00 047** 28.5cm角プラター L-28.7 S-20 H-2.8 **¥3,300** 



**177 00 026** 15cmマルチボウル D-15 H-8.3 **¥1,600** 



**177 00 027** 13.5cmマルチボウル D-13.5 H-7.5 **¥1,100** 



**177 00 028** 12cmマルチボウル D-12 H-6.9 **¥950** 



**177 00 029** 11cmマルチボウル D-11 H-6.3 **¥850** 



**177 00 030** 9cmマルチボウル D-9 H-6.2 **¥700** 



**177 00 023** 17cm洋ボウル D-17 H-7.1 **¥1,800** 



**177 00 025** 13cm洋ボウル D-13 H-5.4 **¥1,100** 



177 00 032 15cm多用井 D-15 H-8.1 ¥1,800



177 00 033 13cm多用井 D-13.3 H-7.2 ¥1,500



**177 00 034** 11.5cm多用井 D-11.5 H-6.1 **¥1,100** 



**176 00 046** 16.5cm ソフトスクエアーボウル D-16.7 H-7 **¥2,200** 



176 00 047 14.5cm ソフトスクエアーボウル D-14.6 H-6.3 **¥1,600** 



176 00 048 12cm ソフトスクエアーボウル D-12.1 H-5.3 ¥1,200



**176 00 049** 9.5cm ソフトスクエアーボウル D-9.6 H-4.3 **¥900** 



176 00 044 13.5cm ソフトスクエアー深皿 D-13.8 H-4.2 ¥1,400



176 00 045 11.5cm ソフトスクエアー深皿 D-11.6 H-3.4 ¥1,000



**177 00 051** カプチーノカップ L-11.1 S-8.4 H-7.9 C-250cc **¥950** 

**127 00 055** 兼用ソーサー D-15.2 H-2.2 **¥600** 



**177 00 052** コーヒーカップ L-10.1 S-7.5 H-6.7 C-160cc **¥850** 

177 00 054 コーヒーソーサー D-14.5 H-1.8 ¥750



177 00 058 エスプレッソカップ L-8.6 S-6.3 H-5.9 C-105cc ¥750 170 00 059 エスプレッソソーサー D-12.8 H-1.7 ¥550





197 00 060 30.5cmスクエアープレート D-30.7 H-2 **¥6,400** 



197 00 061 28cmスクエアープレート D-28 H-2.8 ¥3,900



197 00 062 25.5cmスクエアープレート D-25.8 H-2.6 **¥3,600** 



197 00 063 23cm スクエアープレート D-23.4 H-2.5 ¥3,000 197 00 064 20.5cm スクエアープレート D-20.5 H-2.2 ¥2,400

197 00 065 18cm スクエアープレート D-18 H-2 ¥1,900

197 00 066 16cm スクエアープレート D-16 H-1.8 **¥1,800** 

197 00 067 13.5cm スクエアープレート D-13.8 H-2 ¥1,300


197 00 068 12cm スクエアープレート D-12.2 H-1.7 ¥1,000

197 00 069 11cm

197 00 070 8cm スクエアープレート スクエアープレート D-11.1 H-1.6 D-8.2 H-1.7 ¥850 ¥650



154 00 045 36cm角プラター L-36 S-23.2 H-3.3 **¥6,400** 



154 00 046 32.5cm角プラター L-32.5 S-21 H-3.1 ¥4,300



154 00 047 29.5cm角プラター L-29.5 S-19 H-2.6 ¥3,700



154 00 036 19cmファンネルボウル(角ハマ) D-19 H-6.9 **¥2,100** 



154 00 037 16cmファンネルボウル(角ハマ) D-16 H-6 **¥1,400** 



154 00 038 14cmファンネルボウル(角ハマ) D-14 H-5.1 **¥1,100** 



154 00 091 32cmナロープレート L-32.1 S-6 H-2.6 ¥2,100



154 00 032 16.5cm角ハマ多用井



154 00 033 14cm角ハマ多用丼 D-16.8 H-9.5 **¥2,200** D-14.1 H-8.3 **¥1,900** 



154 00 034 12cm角ハマ多用井 D-12.1 H-7.3 **¥1,100** 



154 00 053 アルコ2連菜 L-17.6 S-7.1 H-2.4 **¥1,400** 



154 00 086 多用カップ D-8.1 H-7.2 C-180cc ¥750



154 00 084 冷酒カップ D-6.5 H-5.7 C-100cc ¥700



154 00 085 冷酒つぎ L-10.2 S-8.3 H-11.2 C-350cc ¥1,500



154 00 067 醤油さし L-7.7 S-5.1 H-9.6 C-120cc **¥2,100** 



141 00 078 13.5cmティア片口小鉢 L-13.6 S-8.5 H-4.6 ¥1,400



141 00 079 11.5cmティア片口小鉢 L-11.6 S-7.3 H-4 **¥1,100** 



141 00 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥800



141 00 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥800



148 00 063 流し呑水 L-8 S-7 H-6.1 ¥800



154 00 082 角レンゲ小 L-10.4 S-5 H-2.6 ¥800



141 40 094 丸片口珍味 L-9.8 S-8 H-4.3 ¥950




141 40 095 手付角吞水 L-8.2 S-7.6 H-5.1 ¥950



148 40 063 流し呑水 L-8.2 S-7 H-6.1 ¥950



154 40 082 角レンゲ小 L-10.4 S-5 H-2.6 ¥950



¥4,100

¥2,300

¥2,000

¥1,300

¥950

¥850

¥700

¥650