



147 00 011
21.5cm深皿
D-21.6 H-4.5 **¥3,300**



147 00 013
18.5cm深皿
D-18.5 H-3.7 **¥2,300**



147 00 014
15.5cm深皿
D-15.5 H-3.1 **¥1,900**



147 00 015
13.5cm深皿
D-13.5 H-2.7 **¥1,600**



147 00 016
10.5cm深皿
D-10.5 H-2.2 **¥1,000**



148 00 035
16cm深ボウル
D-16 H-5.6 **¥2,300**



148 00 036
13.5cm深ボウル
D-13.5 H-4.6 **¥1,800**



148 00 037
10cm深ボウル
D-10 H-4.3 **¥1,100**



148 00 039
7cm深ボウル
D-7 H-3.1 **¥650**



148 00 051
カプチーノカップ
L-11.6 S-9.2 H-6.6 C-235cc **¥950**



148 00 052
コーヒークップ
L-11.2 S-8.7 H-6.3 C-190cc **¥850**



148 00 058
エスプレッソカップ
L-9.4 S-7.3 H-5.2 C-100cc **¥750**

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**

170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**



148 00 011
30.5cmカヌーディッシュ
L-30.8 S-19.5 H-5.2 **¥3,800**



148 00 012
29cmカヌーディッシュ
L-29.2 S-16.8 H-4.6 **¥3,300**




148 00 013
26cmカヌーディッシュ
L-26.3 S-15.4 H-4.3 **¥2,600**



148 00 014
23.5cmカヌーディッシュ
L-23.5 S-13.6 H-3.8 **¥1,800**



148 00 015
21cmカヌーディッシュ
L-21 S-12.3 H-3.3 **¥1,500**



147 00 098
トレイ付丸型3連菜
L-30 S-22.5 H-2.3 **¥4,400**



148 00 096
丸型4連菜
L-35.6 S-9.8 H-2.3 **¥3,300**



148 00 097
丸型3連菜
L-30.4 S-9.6 H-2.3 **¥2,200**



148 00 098
3連菜
L-26 S-8.2 H-2.9 **¥2,300**



148 00 093
2連菜
L-18.3 S-8.5 H-3.1 **¥1,500**



148 00 060
角小鉢
D-8.6 H-3.3 **¥800**



148 00 061
ミニ香水
L-9.6 S-8.8 H-4.4 **¥800**



148 00 062
片口珍珠
L-9.4 S-8.6 H-3.5 **¥800**



148 00 063
流し香水
L-8 S-7 H-6.1 **¥800**



148 00 065
置きレンゲ
L-9.8 S-6 H-7.2 **¥900**

マットブラック



148 30 060
角小鉢
D-8.9 H-3.5 **¥850**



148 30 061
ミニ香水
L-9.9 S-9 H-4.5 **¥850**



148 30 062
片口珍珠
L-9.6 S-8.9 H-3.6 **¥850**




148 30 063
流し香水
L-8.2 S-7 H-6.1 **¥850**



148 30 065
置きレンゲ
L-9.6 S-5.8 H-7.1 **¥900**

レッド



148 40 060
角小鉢
D-8.9 H-3.5 **¥950**



148 40 061
ミニ香水
L-9.9 S-9 H-4.5 **¥950**



148 40 062
片口珍珠
L-9.6 S-8.9 H-3.6 **¥950**



148 40 063
流し香水
L-8.2 S-7 H-6.1 **¥950**



148 40 065
置きレンゲ
L-9.6 S-5.8 H-7.1 **¥1,100**



163 00 002
27cmプレート
D-27.1 H-3.5 ¥3,700



163 00 003
25cmプレート
D-25.3 H-3.3 ¥3,400



163 00 004
23.5cmプレート
D-23.7 H-3.1 ¥3,200



163 00 005
21.5cmプレート
D-21.7 H-2.8 ¥2,600



163 00 020
25cm深皿
D-25 H-3.9 ¥3,800



163 00 021
23.5cm深皿
D-23.7 H-3.6 ¥3,400



163 00 022
21.5cm深皿
D-21.5 H-3.3 ¥2,900



163 00 023
19cm深皿
D-19 H-3 ¥2,500



163 00 010
28cmスープボウル
D-28.2 H-6.1 ¥4,800



163 00 011
24.5cmスープボウル
D-24.7 H-5.1 ¥3,500



163 00 032
15cmマルチボウル
D-15 H-8.3 ¥1,600



163 00 033
13.5cmマルチボウル
D-13.5 H-7.4 ¥1,400



163 00 034
11.5cmマルチボウル
D-11.5 H-6.3 ¥1,100



162 00 062
25cmスクエアプレート
D-25 H-4.3 ¥3,500



162 00 063
22cmスクエアプレート
D-22 H-4 ¥2,700



162 00 064
19.5cmスクエアプレート
D-19.5 H-3.4 ¥2,300



162 00 065
17.5cmスクエアプレート
D-17.5 H-3 ¥2,000



162 00 031
17.5cmマルチボウル
D-17.5 H-9.1 ¥2,200



162 00 032
15cmマルチボウル
D-15 H-7.8 ¥1,900



162 00 033
13cmマルチボウル
D-13 H-6.7 ¥1,500



162 00 034
11.5cmマルチボウル
D-11.5 H-5.9 ¥1,100



162 00 012
22.5cm深皿
L-22.7 S-21.3 H-4.4 ¥2,000



162 00 013
19cm深皿
L-19.1 S-17.9 H-3.7 ¥1,300



162 00 015
13.5cm深皿
L-13.6 S-12.8 H-2.6 ¥1,000



176 00 062
25cm
スクエアプレート
D-25.2 H-3.7
¥3,300



176 00 063
22cm
スクエアプレート
D-22.1 H-3.2
¥2,600



176 00 064
19.5cm
スクエアプレート
D-19.7 H-3
¥2,200



176 00 065
17.5cm
スクエアプレート
D-17.5 H-2.8
¥1,900



176 00 066
15.5cm
スクエアプレート
D-15.8 H-2.4
¥1,600



176 00 067
13.5cm
スクエアプレート
D-13.5 H-2
¥1,300


TRIANGLE | トライアングル



176 00 016
トライアングル 17cmボウル
D-17.3 H-6.9 ¥2,200



176 00 017
トライアングル 14.5cmボウル
D-14.9 H-6.4 ¥1,600



176 00 018
トライアングル 12cmボウル
D-12 H-5.4 ¥1,200



176 00 019
トライアングル 10cmボウル
D-10 H-4.3 ¥900

TWIST | ツイスト



176 00 026
ツイスト 20cmボウル
L-20 S-12.5 H-6.6 **¥2,200**

176 00 027
ツイスト 16.5cmボウル
L-16.5 S-10.7 H-6.3 **¥1,600**

176 00 028
ツイスト 14cmボウル
L-14 S-9.1 H-5.4 **¥1,200**

176 00 029
ツイスト 11cmボウル
L-11.1 S-8 H-4.2 **¥900**

ALMONDEYE | アーモンドアイ




176 00 036
アーモンドアイ 19.5cmボウル
L-19.5 S-14.8 H-6.8 **¥2,200**

176 00 037
アーモンドアイ 16.5cmボウル
L-16.5 S-12.9 H-6.3 **¥1,600**

176 00 038
アーモンドアイ 14cmボウル
L-14 S-10.9 H-5.2 **¥1,200**

176 00 039
アーモンドアイ 11cmボウル
L-11.1 S-9.2 H-4.2 **¥900**

ECLIPSE | エクリプス





176 00 001
エクリプス 16.5cmボウル
L-16.6 S-14.3 H-6.3 **¥1,600**

176 00 002
エクリプス 14cmボウル
L-14 S-11.5 H-5.3 **¥1,200**

176 00 003
エクリプス 11cmボウル
L-11.2 S-9.6 H-4.4 **¥900**

SOFT SQUARE | ソフトスクエアー



176 00 046
ソフトスクエアー 16.5cmボウル
D-16.7 H-7 **¥2,200**

176 00 047
ソフトスクエアー 14.5cmボウル
D-14.6 H-6.3 **¥1,600**

176 00 048
ソフトスクエアー 12cmボウル
D-12.1 H-5.3 **¥1,200**

176 00 049
ソフトスクエアー 9.5cmボウル
D-9.6 H-4.3 **¥900**

SHARP SQUARE | シャープスクエアー



176 00 056
シャープスクエアー 13.5cmボウル
D-13.6 H-6.9 **¥2,200**

176 00 057
シャープスクエアー 12cmボウル
D-12 H-6.5 **¥1,600**

176 00 058
シャープスクエアー 10cmボウル
D-10 H-5.4 **¥1,200**

176 00 059
シャープスクエアー 8cmボウル
D-8.2 H-4.3 **¥900**



156 00 061
26.5cmスクエアプレート
D-26.5 H-3.1 **¥3,700**



156 00 063
23.5cmスクエアプレート
D-23.6 H-2.8 **¥3,000**



156 00 064
20cmスクエアプレート
D-20.1 H-2.6 **¥2,400**



156 00 065
17.5cmスクエアプレート
D-17.5 H-2.3 **¥2,000**



156 00 066
14.5cmスクエアプレート
D-14.8 H-1.9 **¥1,600**



156 00 045
35cm角プラター
L-35 S-23.8 H-3.2 **¥5,000**



156 00 047
31.5cm角プラター
L-31.8 S-21.8 H-3 **¥3,900**



156 00 049
28cm角プラター
L-28.4 S-19.2 H-3 **¥3,300**



164 00 047
34cm細長プレート
L-34.2 S-12.9 H-3.7 **¥4,100**



164 00 048
31cm細長プレート
L-31.4 S-11.9 H-3.1 **¥3,200**



164 00 049
28cm細長プレート
L-28 S-11.5 H-2.8 **¥2,600**



164 00 061
27cmプレート
L-27 S-25.8 H-3.5
¥4,200



164 00 062
24.5cmプレート
L-24.6 S-23 H-3.2
¥3,700



164 00 063
21.5cmプレート
L-21.7 S-20.4 H-2.8
¥2,700



164 00 064
19.5cmプレート
L-19.7 S-18.6 H-2.5
¥2,500



164 00 080
33cm盛皿
L-33 S-21 H-4.7
¥6,100



164 00 072
30cmリップルワイドプレート
L-30 S-26.9 H-2.6 **¥4,800**



164 00 073
26.5cmリップルワイドプレート
L-26.5 S-24 H-2.4 **¥4,100**



164 00 074
24cmリップルワイドプレート
L-24 S-22 H-2.2 **¥3,700**



164 00 071
30cmリップルプレート
L-30 S-26.6 H-2.2 **¥4,500**



156 00 031
17.5cmスクエア深ボウル
D-17.5 H-5.8 **¥2,400**



156 00 032
15cmスクエア深ボウル
D-15 H-4.7 **¥1,900**



156 00 033
12cmスクエア深ボウル
D-12.2 H-4 **¥1,400**



156 00 013
18cmスクエア浅ボウル
D-18.1 H-4.3 **¥2,200**



156 00 015
14cmスクエア浅ボウル
D-14.2 H-3.7 **¥1,600**



156 00 016
10.5cmスクエア浅ボウル
D-10.8 H-2.8 **¥1,000**



157 00 032
15cmデルタ深ボウル
L-15 S-14.4 H-4.9
¥2,000



157 00 033
12.5cmデルタ深ボウル
L-12.5 S-12.2 H-4.1
¥1,400



156 00 051
カプチーノカップ
L-11.9 S-9.4 H-6.1 C-220cc
¥950



156 00 052
コーヒーカップ
L-11.4 S-8.7 H-5.8 C-180cc
¥850



156 00 058
エスプレッソカップ
L-9.8 S-7.3 H-4.8 C-100cc
¥750

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**

170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**



156 00 086
26.5cmルナディッシュ
L-26.8 S-13.4 H-3.1 **¥2,200**



156 00 087
21cmルナディッシュ
L-21.4 S-10.5 H-2.7 **¥1,800**



156 00 088
16cmルナディッシュ
L-16 S-7.8 H-2.1 **¥1,200**

GLANCE グランス

白磁



192 00 085
32.5cmフラット長皿
L-32.5 S-19.9 H-2
¥4,600

192 00 086
31cmフラット長皿
L-31 S-19 H-2
¥3,900

192 00 087
28cmフラット長皿
L-28 S-17.2 H-1.6
¥3,600

192 00 088
25.5cmフラット長皿
L-25.5 S-15.8 H-1.5
¥3,400

192 00 089
23.5cmフラット長皿
L-23.8 S-14.7 H-1.4
¥2,700

墨流(すみながし)




192 31 085
32.5cmフラット長皿
L-32.5 S-19.9 H-2
¥5,000

192 31 086
31cmフラット長皿
L-31 S-19 H-2
¥4,300

192 31 087
28cmフラット長皿
L-28 S-17.2 H-1.6
¥3,900

192 31 088
25.5cmフラット長皿
L-25.5 S-15.8 H-1.5
¥3,600

192 31 089
23.5cmフラット長皿
L-23.8 S-14.7 H-1.4
¥3,000



192 00 060
31cm
スクエアプレート
D-31 H-1.7
¥6,900

192 00 061
26.5cm
スクエアプレート
D-26.6 H-1.7
¥4,200


192 00 062
25cm
スクエアプレート
D-25 H-1.7
¥3,700

192 00 063
23.5cm
スクエアプレート
D-23.5 H-1.7
¥3,400

192 00 064
20cm
スクエアプレート
D-20.4 H-1.5
¥2,600

192 00 065
17cm
スクエアプレート
D-17.4 H-1.3
¥2,000

192 00 066
15.5cm
スクエアプレート
D-15.7 H-1.2
¥1,800




192 00 046
27cm角プラター
L-27 S-17.3 H-1.5 ¥3,400



192 00 047
25cm角プラター
L-25 S-16 H-1.5 ¥3,200



192 00 049
21.5cm角プラター
L-21.5 S-13.8 H-1.5 ¥2,500



192 00 031
26.5cmスクエア4菜皿
D-26.5 H-1.7 ¥4,500



192 00 032
24.5cmスクエア4菜皿
D-24.5 H-1.7 ¥4,100



192 00 033
22.5cmスクエア4菜皿
D-22.7 H-1.6 ¥3,700



192 00 096
丸型6連菜
L-30.2 S-19.1 H-2.4 ¥4,200



192 00 095
6連菜
L-25.2 S-17.1 H-2 ¥3,900



192 00 097
3連菜
L-24.5 S-9 H-2 ¥2,200



192 00 098
2連菜
L-17 S-9 H-2 ¥1,400



192 00 044
25cm細長皿
L-25 S-9 H-1.9 ¥2,000



192 00 099
8.5cm角皿
D-8.9 H-2 ¥950



192 00 056
11cm手付珍味皿
L-11.4 S-10 H-2.4
¥1,100



192 00 058
9cm手付珍味皿
L-9.4 S-8 H-2
¥850



150 00 061
26cm
スクエアプレート
D-26.2 H-2.6
¥4,100



150 00 062
24cm
スクエアプレート
D-24.2 H-2.5
¥3,500



150 00 063
22cm
スクエアプレート
D-22.2 H-2.4
¥2,900



155 00 064
20cm
スクエアプレート
D-20.1 H-2.3
¥2,600



155 00 065
17cm
スクエアプレート
D-17.2 H-2.1
¥2,100



155 00 066
14cm
スクエアプレート
D-14.1 H-1.7
¥1,400



155 00 067
12.5cm
スクエアプレート
D-12.6 H-1.6
¥1,100



150 00 023
14cmアーチボウル
L-14.2 S-8.8 H-4.2
¥1,500



150 00 077
21cmクレイドルボウル
L-21.3 S-15.5 H-11.5
¥3,800



150 00 078
15.5cmクレイドルボウル
L-15.5 S-12.5 H-8.5
¥2,300



150 00 048
13cmクレイドルボウル
L-13.1 S-10.7 H-7.8
¥1,800



150 00 086
15cmスラントールボウル
L-15 S-14.7 H-9
¥2,400



150 00 087
12cmスラントールボウル
L-12.3 S-12 H-7.3
¥1,600



150 00 088
9.5cmスラントールボウル
L-9.7 S-9.5 H-5.8
¥1,200



150 00 016
11.5cm浅ボウル
D-11.5 H-2.4
¥1,200



150 00 019
9cmボウル
D-9 H-2.6
¥950



150 00 027
12cm深鉢
D-12 H-4.9
¥1,500



150 00 010
27cmサラダボウル
D-27 H-12
¥5,600



150 00 031
17cm多用井
D-17.2 H-9.1
¥2,200



150 00 032
14.5cm多用井
D-14.5 H-7.8
¥1,900



150 00 033
13cm多用井
D-13.2 H-7.3
¥1,500



150 00 034
11.5cm多用井
D-11.5 H-6.3
¥1,200



150 00 035
10.5cm多用井
D-10.5 H-6
¥1,000

墨染(すみぞめ)



150 31 010
27cmサラダボウル
D-27 H-12
¥6,100



150 31 031
17cm多用井
D-17.2 H-9.1
¥2,400



150 31 032
14.5cm多用井
D-14.5 H-7.8
¥2,000



150 31 033
13cm多用井
D-13.2 H-7.3
¥1,600



150 31 034
11.5cm多用井
D-11.5 H-6.3
¥1,300



150 31 035
10.5cm多用井
D-10.5 H-6
¥1,100



150 00 099
2連菜
L-17.3 S-9 H-2.7
¥1,500



150 00 058
菱形珍珠小鉢
L-11.9 S-7.9 H-2.6
¥900



150 00 055
ティア3連珍珠
D-12.6 H-2.1
¥1,400



150 00 056
ティア2連珍珠
L-12.9 S-5.7 H-2
¥900



150 00 059
ティア珍珠小鉢
L-7.4 S-5.9 H-4.3
¥900



150 00 057
ティア珍珠
L-6.5 S-5.5 H-2
¥600



150 00 079
7.5cm
クレイドルボウル
L-7.5 S-6.4 H-5.2
¥950



150 00 098
6.5cm角ボウル
D-6.5 H-2.4
¥600



150 00 040
平レンゲ
L-10.9 S-5.4 H-3.1
¥950



150 00 089
7.5cm
スラントールボウル
L-7.6 S-7.4 H-4.5
¥950



150 00 036
立ちレンゲ
L-10.1 S-6.1 H-6.1
¥950

墨染(すみぞめ)



150 31 057
ティア珍珠
L-6.5 S-5.5 H-2
¥650



150 31 079
7.5cm
クレイドルボウル
L-7.5 S-6.4 H-5.3
¥1,100



150 31 098
6.5cm角ボウル
D-6.5 H-2.4
¥650



150 31 040
平レンゲ
L-10.9 S-5.4 H-3.1
¥1,100



150 31 089
7.5cm
スラントールボウル
L-7.6 S-7.4 H-4.5
¥1,100



150 31 036
立ちレンゲ
L-10.1 S-6.1 H-6.1
¥1,100

レッド



150 40 057
ティア珍珠
L-6.5 S-5.5 H-2
¥750



150 40 079
7.5cm
クレイドルボウル
L-7.5 S-6.4 H-5.2
¥1,200



150 40 098
6.5cm角ボウル
D-6.5 H-2.4
¥750



150 40 040
平レンゲ
L-10.9 S-5.4 H-3.1
¥1,200



150 40 089
7.5cm
スラントールボウル
L-7.6 S-7.4 H-4.5
¥1,200



150 40 036
立ちレンゲ
L-10.1 S-6.1 H-6.1
¥1,200





145 00 002
26.5cm皿
L-26.7 S-26.5 H-3.4
¥3,900

145 00 004
23.5cm皿
L-23.7 S-23.5 H-3.2
¥3,700

145 00 005
21cm皿
L-21.1 S-20.8 H-3.1
¥2,500

145 00 006
19cm皿
L-19 S-19 H-2.9
¥2,400

145 00 007
16.5cm皿
L-16.7 S-16.2 H-2.9
¥1,800

145 00 008
13.5cm皿
L-13.6 S-13.3 H-2.1
¥1,400

145 00 010
9.5cm皿
L-9.5 S-9.3 H-2.9
¥1,000



145 00 083
23.5cm細長角皿
L-23.8 S-13.9 H-3
¥2,500

145 00 085
18.5cm細長角皿
L-18.7 S-10.8 H-2.9
¥1,900

145 00 087
16.5cm細長角皿
L-16.5 S-9.2 H-2.9
¥1,300


145 00 088
13.5cm細長角皿
L-13.6 S-7.7 H-2.1
¥1,000

145 00 086
16.5cm長角皿
L-16.5 S-13.6 H-2.9
¥1,600




145 00 051
18.5cmリーフプレート
L-18.5 S-10.1 H-3.6
¥1,400

145 00 091
32.5cmナロープレート
L-32.8 S-6.4 H-2.6
¥2,100



145 00 043
31cmプラター
L-31 S-16.1 H-3.2 ¥3,500



145 00 044
29.5cmプラター
L-29.5 S-10.3 H-2 ¥2,700



145 00 144
トゥインプレート
L-28 S-21.8 H-2.7 ¥3,500



145 00 097
3連菜
L-25.4 S-8.9 H-2.8 ¥2,300



145 00 098
浅型3連菜
L-25.2 S-9 H-1.9 ¥1,800



145 00 039
5cmスタック鉢
L-5 S-5 H-2.9 ¥600



145 00 052
コーヒーカップ
L-11.4 S-8.2 H-7.2 C-180cc
¥1,000

145 00 054
コーヒーソーサー
L-15 S-13.6 H-2.1
¥950



145 00 012
26.5cmベーズリー
L-26.7 S-13.4 H-3.2
¥2,300

145 00 014
23.5cmベーズリー
L-23.5 S-11.8 H-3
¥2,100

145 00 015
21cmベーズリー
L-21.1 S-10.7 H-3
¥1,800

145 00 016
18.5cmベーズリー
L-18.5 S-9.2 H-2.9
¥1,500

145 00 017
16cmベーズリー
L-16.2 S-8.2 H-2.9
¥1,100

145 00 018
13cmベーズリー
L-13.3 S-6.4 H-2.1
¥900

145 00 077
15cmベーズリーボウル
L-15.3 S-7.8 H-4
¥1,500

マットブラック



145 30 012
27cmベーズリー
L-27.2 S-13.7 H-3.3
¥2,300

145 30 014
23.5cmベーズリー
L-23.6 S-12 H-3.2
¥2,100

145 30 015
21.5cmベーズリー
L-21.5 S-10.5 H-3.1
¥1,800

145 30 016
19cmベーズリー
L-19 S-9.6 H-3
¥1,500

145 30 017
16.5cmベーズリー
L-16.6 S-8.1 H-3
¥1,100

145 30 018
13.5cmベーズリー
L-13.6 S-6.6 H-2.2
¥900

BANQUET バンケット
白磁





169 00 060
31cmスクエアプレート
D-31.2 H-4 **¥6,900**

169 00 061
26.5cmスクエアプレート
D-26.5 H-3.2 **¥4,100**

169 00 063
23cmスクエアプレート
D-23.1 H-2.8 **¥3,300**

169 00 064
20cmスクエアプレート
D-20.1 H-2.4 **¥2,600**

169 00 065
18cmスクエアプレート
D-18.3 H-2.2 **¥2,200**

169 00 066
16cmスクエアプレート
D-16.1 H-2.2 **¥1,800**



169 00 045
33cm角プラター
L-33 S-22.1 H-3.2 **¥5,300**




169 00 046
30.5cm角プラター
L-30.4 S-20.2 H-2.8 **¥4,200**



169 00 047
28cm角プラター
L-28 S-18.7 H-2.7 **¥3,500**



169 00 094
33cm細長角プラター
L-33.2 S-12.4 H-2.7 **¥3,500**



169 00 095
30.5cm細長角プラター
L-30.2 S-11.4 H-2.3 **¥2,600**



169 00 011
23cmスクエア深皿
D-23.2 H-4.7 **¥3,800**



169 00 012
21cmスクエア深皿
D-21 H-4.3 **¥2,900**



169 00 023
18cmボウル
D-18 H-5.6 **¥2,500**



169 00 024
16cmボウル
D-16.2 H-4.9 **¥2,100**



169 00 025
14cmボウル
D-14.1 H-4.4 **¥1,800**



169 00 026
12cmボウル
D-12.3 H-3.7 **¥1,400**



169 00 027
10cmボウル
D-10 H-3.2 **¥1,100**



169 00 028
8cmボウル
D-8.3 H-2.8 **¥950**



169 00 037
10.5cm深ボウル
D-10.7 H-5.8 **¥1,400**



169 00 038
9cm深ボウル
D-9.1 H-5.1 **¥1,200**




169 00 039
7.5cm深ボウル
D-7.6 H-4.5 **¥1,000**



169 00 018
9cmスクエア深皿
D-9 H-2 **¥1,000**



169 00 097
3連菜
L-25 S-8.3 H-2.8 **¥2,400**



169 00 098
2連菜
L-16.8 S-8.3 H-2.8 **¥1,500**



169 00 092
4菜皿
D-27.3 H-1.5 **¥4,400**



169 00 091
3菜皿
L-32 S-12 H-1.5 **¥3,600**



169 00 052
コーヒーカップ
L-12 S-9.5 H-7.4 C-176cc **¥1,000**

169 00 055
コーヒーソーサー
D-12.8 H-1.6 **¥950**

COLLINE コリーン

白磁



186 00 061
26cm角皿
D-26.3 H-2.5 **¥4,100**



186 00 063
23cm角皿
D-23 H-2.4 **¥3,400**



186 00 064
20cm角皿
D-20 H-2.1 **¥2,700**



186 00 065
17cm角皿
D-17.3 H-2.1 **¥2,300**



186 00 067
14cm角皿
D-14.2 H-2 **¥1,800**



186 00 069
11cm角皿
D-11.2 H-1.5 **¥1,100**



186 00 018
9cm浅ボウル
D-9.2 H-2 ¥950



186 00 019
8cm浅ボウル
D-8 H-1.7 ¥850




186 00 032
3連菜
L-33.3 S-11 H-1.5 ¥3,000



186 00 045
33.5cm角プラター
L-33.5 S-21.7 H-2.9 ¥5,700



186 00 046
30.5cm角プラター
L-30.7 S-19.4 H-2.8 ¥4,200



186 00 047
29cm角プラター
L-29.1 S-17.6 H-2.7 ¥3,700



186 00 012
24.5cm深皿
L-24.7 S-21.1 H-4.5 ¥4,200



186 00 085
18.5cm長角トレー
L-18.5 S-12.1 H-4.2 ¥2,300



186 00 031
4菜角皿
D-22.2 H-1.5 ¥3,700



186 00 025
13.5cmボウル
D-13.5 H-6.2 ¥1,800



186 00 026
11.5cmボウル
D-11.7 H-5.2 ¥1,400



186 00 027
10cmボウル
D-10 H-4.4 ¥1,100



186 00 028
8cmボウル
D-8.2 H-3.6 ¥950



186 00 096
4連菜鉢
L-17.7 S-17.7 H-3.5 ¥3,200



186 00 097
3連菜鉢
L-24.2 S-10.7 H-3.6 ¥2,500



186 00 098
2連菜鉢
L-16.3 S-10.7 H-3.6 ¥1,600



185 00 062
25cm角皿
D-25 H-3.5 **¥4,200**



185 00 063
23cm角皿
D-23.3 H-3.2 **¥3,500**



185 00 064
21cm角皿
D-21 H-3 **¥3,200**




185 00 065
19cm角皿
D-19 H-2.7 **¥2,600**



185 00 066
16.5cm角皿
D-16.5 H-2.8 **¥2,100**




185 00 032
23cm
ティアベーカー
L-23 S-15.2 H-8
¥3,200




185 00 035
16cm
ティアベーカー
L-16.2 S-10.7 H-5.2
¥1,900



185 00 036
13cm
ティアベーカー
L-13.2 S-8.3 H-4.2
¥1,400



185 00 037
10cm
ティアベーカー
L-10.3 S-6.6 H-3.2
¥1,000



185 00 044
23.5cmティアプレート
L-23.8 S-14.8 H-2.8
¥2,400



185 00 045
21cmティアプレート
L-21.2 S-13.1 H-2.5
¥2,200



185 00 046
18cmティアプレート
L-18.4 S-11.6 H-2.3
¥2,000




185 00 072
31.5cm細長角皿
L-31.6 S-8.7 H-2 **¥2,900**




185 00 015
16cmリーフ深ボウル
L-16 S-12.5 H-7
¥2,100



185 00 016
13cmリーフ深ボウル
L-13 S-10.3 H-5.3
¥1,400



185 00 017
10cmリーフ深ボウル
L-10 S-8.3 H-4.3
¥1,000




187 00 061
26.5cmプレート
D-26.7 H-3.1 **¥4,200**



187 00 062
24cmプレート
D-24 H-2.8 **¥3,500**



187 00 064
21cmプレート
D-21 H-2.6 **¥2,900**



187 00 065
18cmプレート
D-18.2 H-2.5 **¥2,200**



187 00 066
15cmプレート
D-15.2 H-2.2 **¥1,800**



187 00 011
27cmスパゲティボウル
D-27.3 H-4.8 **¥4,400**



187 00 013
19.5cmスープボウル
D-19.7 H-4.7 **¥2,900**



187 00 014
17cmフルーツボウル
D-17.2 H-4.6 **¥2,500**



187 00 040
15cmトールボウル
D-15.2 H-6.9 **¥2,300**



187 00 042
13cmトールボウル
D-13.1 H-6.1 **¥1,900**



187 00 044
11cmトールボウル
D-11.1 H-5.1 **¥1,500**



187 00 086
多用カップ
D-9.6 H-6.5 C-185cc **¥950**



187 00 052
コーヒーカップ
L-11.3 S-9.5 H-6.4 C-185cc **¥1,100**

187 00 055
コーヒーソーサー
D-14.7 H-1.9 **¥1,000**



117 00 061
27cm角皿
D-27.2 H-1.2
¥4,200

117 00 062
25.5cm角皿
D-25.5 H-1.2
¥3,800


117 00 063
23cm角皿
D-22.9 H-1.1
¥3,400

117 00 064
21cm角皿
D-21.1 H-1.1
¥2,900

117 00 065
19cm角皿
D-19.1 H-1.1
¥2,300

117 00 066
17cm角皿
D-17.2 H-1
¥2,100


117 00 067
15cm角皿
D-15.1 H-1
¥1,800




117 00 046
30cm角プラター
L-30.4 S-18.5 H-1.3 ¥3,800




117 00 047
27cm角プラター
L-27.2 S-16.6 H-1.2 ¥3,500




117 00 048
24cm角プラター
L-24.3 S-14.9 H-1.1 ¥3,000




117 00 091
36cm細長角皿
L-36 S-10 H-1 ¥4,100



117 00 093
29cm細長角皿
L-29 S-8.3 H-1 ¥2,500



117 00 094
26cm細長角皿
L-26.2 S-8.3 H-1 ¥2,200



117 00 095
23.5cm細長角皿
L-23.9 S-8.3 H-1 ¥1,900



117 00 096
21cm細長角皿
L-21.8 S-8.3 H-1 ¥1,500



117 00 077
7cm蓋付角珍味鉢
D-7.3 H-4.3
¥1,600



143 00 078
6cm蓋付角珍味鉢
D-6.2 H-4.9
¥1,400



117 00 078
5cm蓋付角珍味鉢
D-5.1 H-4.1
¥1,300



117 00 088
ようじたて
D-4.1 H-4.4
¥750



154 00 067
醤油さし
L-7.7 S-5.1 H-9.6 C-120cc
¥2,100



117 00 085
からし入れ大
D-6.3 H-4.9
¥1,400
(からしスプーン別売)



117 00 086
からし入れ小
D-5.2 H-4.8
¥1,300
(からしスプーン別売)



C17 00 005
からしスプーン
L-8.5
¥300
(18-8ステンレス)



199 00 002
カスター3点セット
¥5,750(からしスプーン別売)
(117 00 088・117 00 085・
154 00 067・117 00 096)



117 31 061
27cm角皿
D-27.2 H-1.2
¥4,500

117 31 062
25.5cm角皿
D-25.5 H-1.2
¥4,200

117 31 063
23cm角皿
D-22.9 H-1.1
¥3,600

117 31 064
21cm角皿
D-21.1 H-1.1
¥3,200

117 31 065
19cm角皿
D-19.1 H-1.1
¥2,500

117 31 066
17cm角皿
D-17.2 H-1
¥2,200

117 31 067
15cm角皿
D-15.1 H-1
¥2,000



117 31 046
30cm角プラター
L-30.4 S-18.5 H-1.3 ¥4,300



117 31 047
27cm角プラター
L-27.2 S-16.6 H-1.2 ¥3,800



117 31 048
24cm角プラター
L-24.3 S-14.9 H-1.2 ¥3,400



117 31 091
36cm細長角皿
L-36 S-10 H-1 ¥4,500



117 31 093
29cm細長角皿
L-29 S-8.3 H-1 ¥2,800



117 31 094
26cm細長角皿
L-26.2 S-8.3 H-1 ¥2,400



117 31 095
23.5cm細長角皿
L-23.9 S-8.3 H-1 ¥2,000



117 31 096
21cm細長角皿
L-21.8 S-8.3 H-1 ¥1,600



117 31 077
7cm蓋付角珍味鉢
D-7.3 H-4.3
¥1,900



143 31 078
6cm蓋付角珍味鉢
D-6.2 H-4.9
¥1,600



117 31 078
5cm蓋付角珍味鉢
D-5.1 H-4.1
¥1,400



117 31 088
ようじたて
D-4.1 H-4.4
¥850



154 31 067
醤油さし
L-7.7 S-5.1 H-10
C-120cc
¥2,300



117 31 085
からし入れ大
D-6.3 H-4.9
¥1,500
(からしスプーン別売)



117 31 086
からし入れ小
D-5.2 H-4.8
¥1,400
(からしスプーン別売)



C17 00 005
からしスプーン
L-8.5
¥300
(18-8ステンレス)



199 31 002
カスター3点セット
¥6,250(からしスプーン別売)
(117 31 088・117 31 085・
154 31 067・117 31 096)



APPETIZER アピタイザー

白磁



143 00 061
28.5cmプレート
L-28.8 S-23.2 H-1.8
¥4,200



143 00 062
26cmプレート
L-26 S-21 H-1.8
¥3,800



143 00 064
23.5cmプレート
L-23.8 S-19.1 H-1.8
¥3,400



143 00 065
21cmプレート
L-21 S-16.8 H-1.3
¥2,900



143 00 067
18.5cmプレート
L-18.7 S-15.1 H-1.4
¥2,100



143 00 045
36cm角プラター
L-36 S-18.3 H-2.2 ¥5,700



143 00 046
31.5cm角プラター
L-31.5 S-16.2 H-1.9 ¥3,500



143 00 047
27.5cm角プラター
L-27.5 S-14.2 H-1.7 ¥3,300



143 00 014
14.5cm取り皿
L-14.5 S-10.6 H-3.2 ¥1,500



143 00 048
25.5cm角プラター
L-25.5 S-13.1 H-1.5 ¥2,900



143 00 049
23cm角プラター
L-23 S-11.7 H-1.4 ¥2,200



143 00 094
30.5cm突出皿
L-30.9 S-8.2 H-1.8 ¥2,400



143 00 095
30cm細長角皿
L-30.2 S-12.1 H-2.1 ¥2,700



143 00 017
22cm4角折込皿
D-22 H-3.6 **¥3,400**



143 00 018
19cm4角折込皿
D-19 H-3.1 **¥2,700**



143 00 019
16cm4角折込皿
D-16 H-2.6 **¥2,100**



143 00 020
13.5cm4角折込皿
D-13.5 H-2 **¥1,600**



164 00 075
26.5cmビジョンペーカー
L-26.7 S-16.5 H-11.7 **¥4,800**



164 00 077
23cmビジョンペーカー
L-23 S-15.3 H-11.2 **¥3,900**



164 00 078
20cmビジョンペーカー
L-20.5 S-13.4 H-9.7 **¥3,000**



164 00 023
16.5cmビジョンボウル
L-16.5 S-14 H-8.5 **¥2,400**



164 00 024
15cmビジョンボウル
L-15 S-12.8 H-8 **¥2,100**



164 00 025
13cmビジョンボウル
L-13 S-11 H-7.3 **¥1,600**



164 00 027
11cmビジョンボウル
L-11 S-9 H-6.5 **¥1,300**



164 00 028
9.5cmビジョンボウル
L-9.5 S-8 H-6 **¥1,100**



164 00 029
7.5cmビジョンボウル
L-7.8 S-6.4 H-5.3 **¥950**



164 40 029
7.5cmビジョンボウル
レッド
L-7.8 S-6.4 H-5.3 **¥1,200**



143 00 024
17cmスラントボウル
L-17.2 S-16.1 H-10.3 **¥2,400**



143 00 025
13.5cmスラントボウル
L-13.6 S-13 H-9 **¥1,800**



143 00 027
10.5cmスラントボウル
L-10.6 S-10.1 H-7 **¥1,200**



143 00 029
7cmスラント珍味
L-7.4 S-7.1 H-4.7 **¥950**



143 00 032
14.5cmマルチボウル
D-14.8 H-8 **¥1,600**



143 00 033
12.5cmマルチボウル
D-12.8 H-6.9 **¥1,300**



143 00 034
11cmマルチボウル
D-11.2 H-5.7 **¥950**



143 00 053
4連珍味
L-23.3 S-6.1 H-2 **¥1,600**



143 00 054
3連珍味
L-17.5 S-6.1 H-2 **¥1,300**



143 00 055
2連珍味
L-11.8 S-6 H-2 **¥950**



143 00 052
スラント2連珍味
L-15 S-7.1 H-4.6 **¥1,500**



143 00 098
10cmミニカップ
L-10.4 S-7.8 H-4.7 **¥1,100**



143 00 099
8.5cmミニカップ
L-8.7 S-6.8 H-3.9 **¥950**



143 00 075
片口手付珍味
L-10 S-7.3 H-4 **¥1,100**



143 00 092
7.5cmトルボウル
D-7.5 H-5.4 **¥750**



143 00 096
手付角珍味鉢
L-7.2 S-5.3 H-3.7 **¥900**



143 00 076
デュードロップ珍味
L-7.4 S-6 H-4.3 **¥900**



123 00 029
7cmミニボウル
D-7 H-2.9 **¥650**

レッド



143 40 098
10cmミニカップ
L-10.4 S-7.8 H-4.7 **¥1,300**



143 40 099
8.5cmミニカップ
L-8.7 S-6.8 H-3.9 **¥1,200**



143 40 075
片口手付珍味
L-10 S-7.3 H-4.3 **¥1,300**



143 40 092
7.5cmトルボウル
D-7.5 H-5.4 **¥950**



143 40 096
手付角珍味鉢
L-7.2 S-5.3 H-3.7 **¥1,100**



143 40 076
デュードロップ珍味
L-7.5 S-6 H-4.3 **¥1,100**



143 00 056
丸珍味
D-6.1 H-1.9 **¥600**



143 00 078
蓋付角珍味
D-6.2 H-4.9 **¥1,400**



143 00 097
スタック珍味
D-6.7 H-4.8 **¥750**



143 31 017
22cm4角折込皿
D-22 H-3.6 ¥3,600



143 31 018
19cm4角折込皿
D-19 H-3.1 ¥3,000



143 31 019
16cm4角折込皿
D-16 H-2.6 ¥2,200



143 31 061
28.5cmプレート
L-28.5 S-23 H-2
¥4,500



143 31 062
26cmプレート
L-26 S-21.5 H-1.8
¥4,100



143 31 064
23.5cmプレート
L-23.8 S-19.1 H-1.5
¥3,600



143 31 065
21cmプレート
L-21 S-16.8 H-1.3
¥3,300



143 31 067
18.5cmプレート
L-18.7 S-15.1 H-1.4
¥2,200



143 31 045
35.5cm角プラター
L-35.9 S-18.3 H-2.2
¥6,000



143 31 046
31cm角プラター
L-31.3 S-16.1 H-2
¥3,800



143 31 047
27.5cm角プラター
L-27.6 S-14.3 H-1.6
¥3,500



143 31 048
25cm角プラター
L-25.4 S-12.8 H-1.6
¥3,300



143 31 049
23cm角プラター
L-23 S-11.7 H-1.4
¥2,300



143 31 094
30.5cm突出皿
L-30.8 S-8.2 H-1.8
¥2,500



143 31 095
30cm細長角皿
L-30.3 S-12.2 H-2.1
¥3,000



143 31 032
14.5cmマルチボウル
D-14.8 H-8
¥1,900



143 31 033
12.5cmマルチボウル
D-12.8 H-6.9
¥1,400



143 31 034
11cmマルチボウル
D-11.2 H-5.7
¥1,100



143 31 024
17cmスラントボウル
L-17.2 S-16.1 H-10.3
¥2,600



143 31 025
13.5cmスラントボウル
L-13.6 S-13 H-9
¥2,000



143 31 027
10.5cmスラントボウル
L-10.6 S-10.1 H-7
¥1,300



143 31 029
7cmスラント珍珠
L-7.4 S-7.1 H-4.7
¥1,100



164 31 023
16.5cmビジョンボウル
L-16.5 S-14 H-8.5
¥2,600



164 31 024
15cmビジョンボウル
L-15.1 S-12.1 H-8
¥2,300



164 31 025
13cmビジョンボウル
L-13.2 S-10.5 H-7
¥1,900



164 31 027
11cmビジョンボウル
L-11.2 S-8.9 H-6.4
¥1,400



164 31 028
9.5cmビジョンボウル
L-9.9 S-7.8 H-6
¥1,200



164 31 029
7.5cmビジョンボウル
L-7.8 S-6.4 H-5.3
¥1,100



143 31 098
10cmミニカップ
L-10.3 S-7.5 H-4.5 ¥1,200



143 31 099
8.5cmミニカップ
L-8.7 S-6.8 H-3.9 ¥1,100



143 31 075
片口手付珍珠
L-10 S-7.3 H-4 ¥1,200



143 31 092
7.5cmトールボウル
D-7.5 H-5.4 ¥850



143 31 097
スタック珍珠
D-6.7 H-4.8 ¥850



143 31 096
手付角珍珠鉢
L-7.6 S-5.3 H-3.3 ¥1,000



143 31 056
丸珍珠
D-6.1 H-1.9 ¥650



143 31 078
蓋付角珍珠
D-6.2 H-4.9 ¥1,600

CHIFFON シフォン
ニューボン





151 20 001
30cm大皿
D-30 H-3.3 **¥3,800**



151 20 002
27cmディナー皿
D-27 H-2.7 **¥2,000**



151 20 003
24cmミート皿
D-24 H-2.4 **¥1,300**



151 20 005
20cmケーキ皿
D-20 H-2.4 **¥950**



151 20 008
16cmパン皿
D-16.2 H-1.9 **¥700**



151 20 010
11cm小皿
D-11 H-2 **¥600**



151 20 025
14cmボウル
D-14 H-5 **¥950**



151 20 026
11.5cmボウル
D-11.7 H-4.5 **¥850**



151 20 027
9cmボウル
D-9.1 H-4 **¥700**



151 20 012
23cmスープボウル
D-23 H-4 **¥1,400**



151 20 013
19cmクープスープボウル
D-19 H-3.3 **¥1,100**



151 20 014
16cmフルーツボウル
D-16 H-3 **¥850**



151 20 051
アメリカンカップ
L-11 S-8.7 H-7.4 C-260cc **¥950**
151 20 055
兼用ソーサー
D-15 H-2.2 **¥650**



151 20 052
コーヒーカップ
L-10.5 S-8 H-6.7 C-180cc **¥850**
151 20 056
コーヒーソーサー
D-13.6 H-2 **¥600**



151 20 053
ティーカップ
L-11.3 S-9 H-5.9 C-200cc **¥900**
151 20 055
兼用ソーサー
D-15 H-2.2 **¥650**

BONE CERAM

ボーンセラム

ニューボン



121 20 001
31cm大皿
D-31.2 H-3 **¥3,500**



121 20 002
26.5cmディナー皿
D-26.7 H-2.5 **¥2,100**



121 20 003
25cmディナー皿
D-25 H-2.5 **¥1,800**



121 20 004
23cmミート皿
D-23.2 H-2.2 **¥1,200**



121 20 005
22cmミート皿
D-22.3 H-2 **¥1,100**



121 20 006
19cmケーキ皿
D-19.1 H-2 **¥750**



121 20 008
15.5cmバン皿
D-15.6 H-2 **¥650**



121 20 010
10cm小皿
D-10.2 H-1.9 **¥600**



121 20 040
34cmピザプレート
D-34.2 H-1.8
¥5,300



121 20 042
28cmピザプレート
D-28 H-1.7
¥3,400



121 20 043
25.5cmピザプレート
D-25.5 H-1.7
¥3,200



121 20 044
23cmピザプレート
D-23 H-1.7
¥2,200



121 20 062
26cmスクエアプレート
D-26.2 H-3
¥3,500

121 20 063
23cmスクエアプレート
D-23 H-2.5
¥2,900

121 20 064
20cmスクエアプレート
D-20 H-2.4
¥2,500

121 20 066
16cmスクエアプレート
D-16 H-2.2
¥1,700



121 20 071
27cmカヌーベーカー
L-27.2 S-13.9 H-7
¥3,500



121 20 046
31cmプラター
L-31 S-21 H-3
¥3,700

121 20 047
26.5cmプラター
L-26.7 S-17.2 H-3
¥2,500



121 20 012
22.5cmカレースバゲティボウル
D-22.7 H-3.5
¥1,300



121 20 034
16cmデュードロップボウル
L-16.1 S-13.3 H-5.1
¥1,500



121 20 035
13cmデュードロップボウル
L-13.1 S-11 H-4.6
¥1,100



121 20 037
10cmデュードロップボウル
L-10.2 S-8.5 H-3.5
¥850



121 20 013
18.5cmスープボウル
D-18.7 H-4
¥950

121 20 014
15.5cmフルーツボウル
D-15.6 H-3.3
¥850

121 20 015
12cmスモールボウル
D-12.3 H-3.1
¥700



121 20 025
14cmボウル
D-14 H-6.2
¥950



121 20 073
18.5cmシチュー
L-18.7 S-16.8 H-3.7
¥1,800



121 20 072
16cmグラタン
L-16.2 S-15 H-5
¥1,600



121 20 060
シュガー
D-8.8 H-9.7 C-275cc
¥2,200



121 20 067
クリーマー
L-11.4 S-7.5 H-6.8 C-200cc
¥2,000



121 20 051
アメリカンカップ
L-11.6 S-8.6 H-7.6 C-280cc
¥950

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 052
コーヒーカップ
L-10.3 S-7.8 H-6.7 C-200cc
¥850

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 058
デミタスカップ
L-8.6 S-6.5 H-5.5 C-105cc
¥750

121 20 059
デミタスソーサー
D-12.7 H-1.7
¥550



121 20 080
ブイヨンカップ
D-9 H-6.3 C-220cc
¥850



121 20 050
マグカップ
L-10.3 S-7.5 H-8.8 C-280cc
¥1,000



121 20 056
ラテカップ
L-13.9 S-11.2 H-6 C-345cc
¥950

121 20 057
ラテソーサー
D-17 H-1.9
¥600



121 20 053
ティーカップ
L-11.8 S-9.2 H-5.4 C-200cc
¥900

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 054
片手スープカップ
L-12.5 S-10.2 H-5.5 C-270cc
¥1,200

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 152
M型コーヒーカップ
L-10.6 S-8.3 H-6.4
C-180cc
¥850

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 153
M型ティーカップ
L-11.6 S-9.1 H-5
C-155cc
¥850

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 151
M型アメリカンカップ
L-10.6 S-8.3 H-7.5
C-200cc
¥950

121 20 055
兼用ソーサー
D-13.7 H-2.1
¥600



121 20 158
M型デミタスカップ
L-8.5 S-6.2 H-5.7
C-100cc
¥750

121 20 059
デミタスソーサー
D-12.7 H-1.7
¥550



121 20 252
M型高台コーヒーカップ
L-10.1 S-7.6 H-8.2
C-185cc
¥1,100

121 20 255
M型高台カップ兼用ソーサー
D-15.2 H-2.5
¥600



121 20 251
M型高台アメリカンカップ
L-10.6 S-8.2 H-9.4
C-220cc
¥1,200

121 20 255
M型高台カップ兼用ソーサー
D-15.2 H-2.5
¥600

BON CUISINE

ボン クジーン

ニューボン



131 20 042
33cmプラター
L-33 S-26.5 H-3.5 **¥3,400**



131 20 044
28.5cmプラター
L-28.5 S-23 H-2.9 **¥2,400**



131 20 001
31.5cm大皿
D-31.5 H-3 **¥3,700**



131 20 002
27cmディナー皿
D-27 H-2.4 **¥2,000**



131 20 004
23cmミート皿
D-23.3 H-2 **¥1,200**



131 20 006
19.5cmケーキ皿
D-19.5 H-1.8 **¥950**



131 20 007
17.5cmパン皿
D-17.5 H-1.8 **¥700**



131 20 008
15.5cmパン皿
D-15.5 H-1.5 **¥600**



131 20 062
25.5cm
スクエアプレート
D-25.8 H-2.6 **¥3,400**



131 20 063
23.5cm
スクエアプレート
D-23.5 H-2.5 **¥2,900**



131 20 064
20.5cm
スクエアプレート
D-20.5 H-2.2 **¥2,300**



131 20 065
18cm
スクエアプレート
D-18 H-2 **¥1,800**



131 20 067
13.5cm
スクエアプレート
D-13.8 H-2 **¥1,200**



131 20 068
12cm
スクエアプレート
D-12.2 H-1.7 **¥1,000**




131 20 069
11cm
スクエアプレート
D-11.1 H-1.6 **¥850**



131 20 070
8cm
スクエアプレート
D-8.2 H-1.7 **¥650**



131 20 045
36cm角プラター
L-36 S-23.2 H-3.3 **¥6,100**



131 20 046
32.5cm角プラター
L-32.5 S-21 H-3.1 **¥4,100**



131 20 047
29.5cm角プラター
L-29.5 S-19 H-2.6 **¥3,500**



131 20 010
25.5cmリムスープ皿
D-25.5 H-4 **¥1,900**



131 20 011
23cmリムスープ皿
D-23 H-3.7 **¥1,200**



131 20 096
15cmタルト
D-15.2 H-3.3 **¥1,100**



131 20 097
12.5cmタルト
D-12.6 H-3.1 **¥700**



131 20 098
10cmタルト
D-10.3 H-2.9 **¥650**



131 20 099
8cmタルト
D-8.2 H-2.6 **¥600**



131 20 086
13cmスフレ
D-13 H-6.2 C-500cc **¥1,100**



131 20 088
9.5cmスフレ
D-9.7 H-4.7 C-220cc **¥600**

131 20 087
11cmスフレ
D-11.2 H-5.6 C-330cc **¥850**

131 20 089
8cmスフレ
D-8.2 H-4.3 C-130cc **¥500**



131 20 012
22cmスープパグティボウル
D-22.2 H-4.2 **¥1,300**



131 20 013
19cmスープボウル
D-19 H-4 **¥950**



131 20 014
15.5cmフルーツボウル
D-15.8 H-3.3 **¥750**



131 20 015
12.5cmスモールボウル
D-12.6 H-2.9 **¥650**



131 20 016
9.5cmスモールボウル
D-9.6 H-2.6 **¥600**



131 20 017
8cmスモールボウル
D-8 H-2 **¥600**



131 20 034
16cmオートミール
D-16.2 H-4.8 **¥850**



131 20 076
19cm舟型オープンパン
L-19 S-13 H-3.8 **¥1,600**



131 20 170
キャセロール蓋
D-13 H-5.2 **¥1,100**



131 20 081
ソースボット
L-19.5 S-9.5 H-7.3 C-290cc **¥2,700**

121 20 072
キャセロール身
L-16.2 S-15 H-5 **¥1,600**



131 20 050
片手スープカップ
L-12 S-9.5 H-7.2 C-300cc
¥950



131 20 054
両手付スープカップ
L-16.1 S-11 H-6 C-290cc
¥1,300



131 20 167
クリーマー
L-5.7 S-5.2 H-3.3 C-45cc
¥750

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



131 20 051
カプチーノカップ
L-11.2 S-8.5 H-6.5 C-215cc
¥850



131 20 052
コーヒーカップ
L-10.2 S-7.7 H-6.5 C-170cc
¥750



131 20 053
ティーカップ
L-12.5 S-10 H-5.5 C-250cc
¥850



131 20 058
エスプレッソカップ
L-8.8 S-6.5 H-5.3 C-105cc
¥750

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

121 20 059
エスプレッソソーサー
D-12.7 H-1.7 **¥550**



122 20 000
35.5cm丸皿
D-35.7 H-4.2 **¥10,000**



122 20 001
31.5cm丸皿
D-31.6 H-3.7 **¥3,800**



122 20 003
25.5cm丸皿
D-25.5 H-3.4 **¥1,800**



122 20 004
23cm丸皿
D-23.2 H-3.2 **¥1,100**



122 20 005
21cm丸皿
D-21.3 H-3 **¥950**



122 20 006
19cm丸皿
D-19.3 H-2.7 **¥850**



122 20 007
17cm丸皿
D-17.2 H-2.5 **¥700**



122 20 008
15cm丸皿
D-15 H-2.5 **¥650**



122 20 009
13cm丸皿
D-13 H-2.3 **¥600**



122 20 010
10cm丸皿
D-10.2 H-2 **¥600**



122 20 040
36cmオーバル皿
L-36.2 S-16.3 H-3 **¥5,700**



122 20 041
31cmオーバル皿
L-31.3 S-14 H-3 **¥3,000**



122 20 042
26cmオーバル皿
L-26.4 S-11.5 H-2.2 **¥1,600**



122 20 043
31cmプラター
L-31 S-21.7 H-3.8 **¥3,400**



122 20 075
25.5cmペーカー
L-25.8 S-18.2 H-4.6 **¥3,000**



122 20 076
20cm舟型グラタン
L-20.3 S-13.4 H-4 **¥1,600**



122 20 023
19cmボウル
D-19 H-6.7 **¥1,800**

122 20 046
25.5cmプラター
L-25.8 S-18 H-3.1 **¥2,300**

122 20 047
23cmプラター
L-23.2 S-16.2 H-2.9 **¥1,600**

122 20 077
15cm舟型グラタン
L-15.4 S-10.3 H-3.4 **¥1,400**

122 20 024
16cmボウル
D-16 H-6 **¥1,400**



122 20 025
12.5cmボウル
D-12.8 H-5.4 **¥950**



122 20 014
17.5cm浅ボウル
D-17.8 H-4.2 **¥1,100**



122 20 016
9.5cm浅ボウル
D-9.6 H-2.9 **¥600**



122 20 012
17cm切立ボウル
D-17 H-4.7 **¥1,400**



122 20 033
11.5cmライスボウル
D-11.8 H-6.2 **¥750**



122 20 080
ピヨンカップ
D-10 H-6.3 C-250cc
¥750

122 20 027
9.5cmボウル
D-9.6 H-4 **¥750**

122 20 015
13.5cm浅ボウル
D-13.7 H-3.8 **¥750**

131 20 017
8cm浅ボウル
D-8 H-2 **¥600**



122 20 058
湯呑み
D-7.7 H-7.5 C-200cc
¥700



122 20 052
カプチーノカップ
L-11.4 S-9 H-6.5 C-250cc
¥850



122 20 057
ティーポット
L-17.5 S-10 H-10.5 C-390cc
¥3,600



122 20 063
クリーマー
L-10 S-7.5 H-7.3 C-150cc
¥2,000

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



122 20 069
スティックシュガー
L-8.5 S-6.4 H-7.9
¥1,400



122 20 060
シュガー
D-9.2 H-8.5 C-240cc
¥2,100



122 20 067
手付醤油入れ
L-12.7 S-8 H-10.2 C-230cc
¥2,200



122 20 088
ようじ立て
D-5.3 H-4.6
¥650

122 20 064
醤油入れ
L-10.1 S-8 H-10.2 C-230cc
¥2,100



122 20 073
仕切り皿
L-13.4 S-8.2 H-2.2
¥1,200



122 20 089
箸置き
L-5.6 S-2 H-1.4
¥350

122 20 085
マスタード
D-6.1 H-6.7
¥900

122 20 079
カスター皿
L-21.2 S-9.1 H-1.4
¥1,400



125 20 001
31.5cm丸皿
D-31.5 H-3.4 ¥3,700



125 20 002
26cm丸皿
D-26.4 H-2.8 ¥2,100



125 20 004
23cm丸皿
D-23 H-2.3 ¥1,200



125 20 005
21cm丸皿
D-21.1 H-2.1 ¥1,100



125 20 006
19cm丸皿
D-19 H-2 ¥950



125 20 007
17cm丸皿
D-17 H-1.8 ¥850



125 20 008
15cm丸皿
D-15 H-1.6 ¥700



177 20 040
32.5cmティアプレート
L-32.5 S-25.1 H-3.9 **¥4,000**



177 20 041
28.5cmティアプレート
L-28.6 S-22.1 H-3.3 **¥3,100**



177 20 042
24cmティアプレート
L-24 S-18.5 H-3 **¥2,300**



177 20 044
17cmティアプレート
L-17 S-13.3 H-2.5 **¥1,500**



177 20 075
17cmティア小鉢
L-17.2 S-10.6 H-5.4
¥1,500



177 20 076
15cmティア小鉢
L-15.4 S-9.4 H-4.9
¥1,300



177 20 077
13cmティア小鉢
L-13.1 S-8.1 H-4.3
¥1,000



177 20 078
13.5cmティアソースポット
L-13.6 S-8.5 H-4.6
¥1,300



177 20 079
11.5cmティアソースポット
L-11.6 S-7.3 H-4
¥1,000



177 20 032
15cm多用井
D-15 H-8.1 **¥1,600**



177 20 033
13cm多用井
D-13.3 H-7.2 **¥1,400**



177 20 034
11.5cm多用井
D-11.5 H-6.1 **¥950**



177 20 023
17cm洋ボウル
D-17 H-7.1 **¥1,600**



177 20 025
13cm洋ボウル
D-13 H-5.4 **¥1,100**



177 20 026
15cmマルチボウル
D-15 H-8.3 **¥1,500**



177 20 027
13.5cmマルチボウル
D-13.5 H-7.5 **¥1,000**



177 20 028
12cmマルチボウル
D-12 H-6.9 **¥850**



177 20 029
11cmマルチボウル
D-11 H-6.3 **¥700**



177 20 030
9cmマルチボウル
D-9 H-6.2 **¥650**



177 20 051
カプチーノカップ
L-11 S-8.3 H-7.8 C-230cc
¥950



177 20 052
コーヒーカップ
L-10.1 S-7.5 H-6.7 C-160cc
¥850



177 20 058
エスプレッソカップ
L-9 S-6.5 H-6 C-100cc
¥750



177 20 063
クリーマー小
L-5.2 S-4.4 H-4 C-26cc
¥850

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**

121 20 059
エスプレッソソーサー
D-12.7 H-1.7 **¥550**



156 20 001
32.5cmクーブ皿
D-32.5 H-3.4 **¥3,700**



156 20 002
27.5cmクーブ皿
D-27.6 H-3.2 **¥2,100**



156 20 003
25.5cmクーブ皿
D-25.8 H-3 **¥1,800**



156 20 004
23cmクーブ皿
D-23.3 H-2.8 **¥1,100**



156 20 005
21cmクーブ皿
D-21.1 H-2.6 **¥1,000**



156 20 006
19cmクーブ皿
D-19.3 H-2.5 **¥850**



156 20 007
17.5cmクーブ皿
D-17.8 H-2.2 **¥700**



156 20 008
15.5cmクーブ皿
D-15.8 H-2 **¥650**



156 20 009
13.5cmクーブ皿
D-13.7 H-2 **¥600**



156 20 061
26.5cmスクエアプレート
D-26.5 H-3.1 **¥3,500**



156 20 063
23.5cmスクエアプレート
D-23.6 H-2.8 **¥2,900**



156 20 064
20cmスクエアプレート
D-20.1 H-2.6 **¥2,300**



156 20 065
17.5cmスクエアプレート
D-17.5 H-2.3 **¥1,900**



156 20 066
14.5cmスクエアプレート
D-14.8 H-1.9 **¥1,500**



156 20 045
35cm角プラター
L-34 S-23 H-3.2 **¥4,800**



156 20 047
31.5cm角プラター
L-31.8 S-21.8 H-3 **¥3,700**



156 20 049
28cm角プラター
L-28.4 S-19.2 H-3 **¥3,100**



156 20 031
17.5cmスクエア深ボウル
D-17.5 H-5.8 **¥2,300**



156 20 032
15cmスクエア深ボウル
D-15 H-4.7 **¥1,800**



156 20 033
12cmスクエア深ボウル
D-12.2 H-4 **¥1,300**



156 20 013
18cmスクエア浅ボウル
D-18.1 H-4.3 **¥2,100**



156 20 015
14cmスクエア浅ボウル
D-14.2 H-3.7 **¥1,500**



156 20 016
10.5cmスクエア浅ボウル
D-10.8 H-2.8 **¥950**



157 20 035
14.5cmマルチボウル
D-14.7 H-8.1 **¥1,500**



157 20 037
12.5cmマルチボウル
D-12.7 H-7 **¥1,300**



157 20 039
11cmマルチボウル
D-11.2 H-6.1 **¥950**



156 20 080
31.5cmクロワッサン
L-31.5 S-14 H-3.3 **¥3,300**



156 20 082
23.5cmクロワッサン
L-23.5 S-10.4 H-3.1 **¥2,100**



156 20 083
19.5cmクロワッサン
L-19.6 S-8.7 H-2.4 **¥1,500**



156 20 051
カプチーノカップ
L-11.9 S-9.4 H-6.1 C-220cc **¥950**
131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



156 20 052
コーヒーカップ
L-11.4 S-8.7 H-5.8 C-180cc **¥850**
131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



156 20 058
エスプレッソカップ
L-9.8 S-7.3 H-4.8 C-100cc **¥750**
121 20 059
エスプレッソソーサー
D-12.7 H-1.7 **¥550**



157 20 063
クリーマー小
L-4.1 S-3.7 H-4.6 C-25cc **¥850**





132 20 001
31.5cm大皿
D-31.5 H-3.4
¥3,700

132 20 002
27.5cmディナー皿
D-27.5 H-3.2
¥2,100

132 20 004
23cmミート皿
D-23 H-3
¥1,200

132 20 006
19.5cmケーキ皿
D-19.5 H-2.5
¥1,000

132 20 008
15.5cmパン皿
D-15.5 H-2.2
¥700



132 20 046
31cm角プラター
L-31.3 S-21.4 H-2.9 ¥3,700

132 20 047
28.5cm角プラター
L-28.9 S-19.7 H-2.7 ¥3,300

132 20 048
26cm角プラター
L-26.2 S-18 H-2.7 ¥3,000

132 20 075
14.5cm角小皿 CN
L-14.3 S-9.3 H-1.5 ¥1,200



121 20 012
22.5cmカレースパゲティボウル
D-22.7 H-3.5
¥1,300

122 20 023
19cmボウル
D-19 H-6.7
¥1,800

122 20 024
16cmボウル
D-16 H-6
¥1,400

122 20 025
12.5cmボウル
D-12.8 H-5.4
¥950

122 20 027
9.5cmボウル
D-9.6 H-4
¥750



132 20 014
16cmフルーツボウル
D-16 H-4.2 ¥900

132 20 016
13cmデザートボウル
D-13.3 H-3.4 ¥750

193 20 054
22cm浅オープンパン
L-22.1 S-19 H-4.3 ¥2,100

132 20 074
19cm浅オープンパン
L-19.4 S-16.5 H-3.9 ¥1,800

132 20 090
スフレカップ
D-8.4 H-5.3
¥600

132 20 050
マグカップ
L-11 S-8.5 H-7.8 C-270cc
¥1,000



132 20 051
カプチーノカップ
L-11.3 S-9 H-6.5 C-200cc
¥900

132 20 152
Nコーヒーカップ
L-10.7 S-8.4 H-6.1 C-170cc
¥750

132 20 058
エスプレッソカップ
L-9.1 S-7.2 H-5.2 C-100cc
¥750

132 20 052
コーヒーカップ
L-10.4 S-8 H-7.5 C-200cc
¥850

132 20 063
クリーマー
L-4.6 S-4.1 H-3.5 C-24cc
¥750

131 20 055
兼用ソーサー
D-15 H-2.1 ¥600

131 20 055
兼用ソーサー
D-15 H-2.1 ¥600

121 20 059
エスプレッソソーサー
D-12.7 H-1.7 ¥550

132 20 056
コーヒーソーサー
D-15 H-2 ¥600

