

COUNTRY SIDE  
STORM GRAY | ストーム グレー



**111 73 002**  
26cmディナー皿  
D-26 H-3.2  
¥2,300

**111 73 004**  
23cmミート皿  
D-23.2 H-3  
¥1,600

**111 73 006**  
19.5cmケーキ皿  
D-19.8 H-2.9  
¥1,200

**111 73 008**  
15cmパン皿  
D-15 H-2.5  
¥950



**111 73 097**  
19cmラザニア  
L-19.7 S-12.2 H-3.5 ¥1,800



**111 73 072**  
グラタン  
L-16 S-14.4 H-5.1 ¥2,200



**161 73 012**  
22cmパスタボウル  
D-22.4 H-3.7 ¥1,600



COUNTRY SIDE



**113 73 046**  
28.5cmオーバルプラター  
L-29.1 S-22.5 H-4 ¥3,500



**113 73 071**  
27cmオーバルペーカー  
L-27 S-17.2 H-5.5 ¥3,500



**111 73 046**  
31.5cmプラター  
L-31.8 S-22 H-3.7 ¥4,800



**111 73 047**  
26cmプラター  
L-26.2 S-18.2 H-2.7 ¥3,200



**111 73 048**  
24cmプラター  
L-24 S-17 H-2.7 ¥2,300



**111 73 021**  
23cmボウル  
D-23.2 H-8.3 ¥2,900



**111 73 023**  
20cmボウル  
D-20 H-7 ¥2,600



**111 73 024**  
17cmボウル  
D-17 H-6.3 ¥1,500



**111 73 025**  
13.5cmボウル  
D-13.7 H-5.5 ¥1,000



**111 73 027**  
10cmボウル  
D-10.2 H-4.1 ¥800



**113 73 051**  
ダイナーマグカップ  
L-12.2 S-8.8 H-9.3  
C-345cc ¥1,400



**113 73 052**  
ダイナーカップ  
L-11.4 S-8 H-8.6  
C-240cc ¥1,300



**113 73 050**  
高台削りマグカップ  
L-12.2 S-8.8 H-10.4  
C-330cc ¥1,400



**111 73 052**  
コーヒーカップ  
L-10.5 S-7.8 H-7.3  
C-180cc ¥900



**111 73 053**  
ティーカップ  
L-12.5 S-9.9 H-5.8  
C-270cc ¥950



**113 73 056**  
ダイナースープカップ  
L-13.2 S-10.5 H-6.3  
C-340cc ¥1,600



**111 73 058**  
片手スープカップ  
L-15 S-12.1 H-6.4  
C-340cc ¥1,400

**161 73 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥700

**161 73 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥700

**111 73 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥700

**111 73 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥750

**111 73 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥750

**111 73 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥750



**111 60 002**  
26cmディナー皿  
D-26 H-3.2  
¥2,100

**111 60 004**  
23cmミート皿  
D-23.2 H-3  
¥1,500

**111 60 006**  
19.5cmケーキ皿  
D-19.8 H-2.9  
¥1,100

**111 60 008**  
15cmパン皿  
D-15 H-2.5  
¥850



**111 60 097**  
19cmラザニア  
L-19.7 S-12.2 H-3.5  
¥1,700



**111 60 072**  
グラタン  
L-16 S-14.4 H-5.1  
¥2,100



**161 60 012**  
22cmバスタボウル  
D-22.4 H-3.7  
¥1,500



**113 60 044**  
28.5cmオーバルプラター  
L-29.1 S-22.5 H-4 ¥3,200



**113 60 071**  
27cmオーバルペーパー  
L-27 S-17.2 H-5.5 ¥3,200



**111 60 043**  
31.5cmプラター  
L-31.8 S-22 H-3.7 ¥4,600



**111 60 045**  
26cmプラター  
L-26.2 S-18.2 H-2.7 ¥2,900



**111 60 046**  
24cmプラター  
L-24 S-17 H-2.7 ¥2,100



**111 60 021**  
23cmボウル  
D-23.2 H-8.3  
¥2,600



**111 60 023**  
20cmボウル  
D-20 H-7  
¥2,400



**111 60 024**  
17cmボウル  
D-17 H-6.3  
¥1,400



**111 60 025**  
13.5cmボウル  
D-13.7 H-5.5  
¥900



**111 60 027**  
10cmボウル  
D-10.2 H-4.1  
¥750



**113 60 063**  
クリーマー  
L-10.7 S-8.1 H-8  
C-200cc ¥1,400



**113 60 051**  
ダイナーマグカップ  
L-12.2 S-8.8 H-9.3  
C-345cc ¥1,300



**113 60 052**  
ダイナーカップ  
L-11.4 S-8 H-8.6  
C-240cc ¥1,200



**113 60 053**  
ダイナーコーヒーカップ  
L-10.1 S-7.5 H-7.8  
C-200cc ¥1,100



**113 60 050**  
高台削りマグカップ  
L-12.2 S-8.8 H-10.4  
C-330cc ¥1,300



**111 60 052**  
コーヒーカップ  
L-10.5 S-7.8 H-7.3  
C-180cc ¥850



**111 60 053**  
ティーカップ  
L-12.5 S-9.9 H-5.8  
C-270cc ¥900



**113 60 056**  
ダイナースープカップ  
L-13.2 S-10.5 H-6.3  
C-340cc ¥1,500



**111 60 058**  
片手スープカップ  
L-15 S-12.1 H-6.4  
C-340cc ¥1,300

**161 60 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 60 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**161 60 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 60 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**111 60 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 60 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 60 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

COUNTRY SIDE  
JADE | ジェイド



**111 70 002**  
26cmディナー皿  
D-26 H-3.2  
¥2,100

**111 70 004**  
23cmミート皿  
D-23.2 H-3  
¥1,500

**111 70 006**  
19.5cmケーキ皿  
D-19.8 H-2.9  
¥1,100

**111 70 008**  
15cmパン皿  
D-15 H-2.5  
¥850



**111 70 097**  
19cmラザニア  
L-19.7 S-12.2 H-3.5  
¥1,700



**111 70 072**  
グラタン  
L-16 S-14.4 H-5.1  
¥2,100



**161 70 012**  
22cmパスタボウル  
D-22.4 H-3.7  
¥1,500



COUNTRY SIDE



**113 70 044**  
28.5cmオーバルプラター  
L-29.1 S-22.5 H-4  
¥3,200



**113 70 071**  
27cmオーバルベーカー  
L-27 S-17.2 H-5.5  
¥3,200



**111 70 043**  
31.5cmプラター  
L-31.8 S-22 H-3.7  
¥4,600



**111 70 045**  
26cmプラター  
L-26.2 S-18.2 H-2.7  
¥2,900



**111 70 046**  
24cmプラター  
L-24 S-17 H-2.7  
¥2,100



**111 70 021**  
23cmボウル  
D-23.2 H-8.3  
¥2,600



**111 70 023**  
20cmボウル  
D-20 H-7  
¥2,400



**111 70 024**  
17cmボウル  
D-17 H-6.3  
¥1,400



**111 70 025**  
13.5cmボウル  
D-13.7 H-5.5  
¥900



**111 70 027**  
10cmボウル  
D-10.2 H-4.1  
¥750



**113 70 063**  
クリーマー  
L-10.7 S-8.1 H-8  
C-200cc ¥1,400



**113 70 051**  
ダイナーマグカップ  
L-12.2 S-8.8 H-9.3  
C-345cc ¥1,300



**113 70 052**  
ダイナーカップ  
L-11.4 S-8 H-8.6  
C-240cc ¥1,200



**113 70 053**  
ダイナーコーヒーカップ  
L-10.1 S-7.5 H-7.8  
C-200cc ¥1,100



**113 70 050**  
高台削りマグカップ  
L-12.2 S-8.8 H-10.4  
C-330cc ¥1,300



**111 70 052**  
コーヒーカップ  
L-10.5 S-7.8 H-7.3  
C-180cc ¥850



**111 70 053**  
ティーカップ  
L-12.5 S-9.9 H-5.8  
C-270cc ¥900



**113 70 056**  
ダイナースープカップ  
L-13.2 S-10.5 H-6.3  
C-340cc ¥1,500



**111 70 058**  
片手スープカップ  
L-15 S-12.1 H-6.4  
C-340cc ¥1,300

**161 70 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 70 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**161 70 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 70 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**111 70 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 70 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 70 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700



**111 86 002**  
26cmディナー皿  
D-26 H-3.2  
¥2,100

**111 86 004**  
23cmミート皿  
D-23.2 H-3  
¥1,500

**111 86 006**  
19.5cmケーキ皿  
D-19.8 H-2.9  
¥1,100

**111 86 008**  
15cmパン皿  
D-15 H-2.5  
¥850



**111 86 097**  
19cmラザニア  
L-19.7 S-12.2 H-3.5  
¥1,700



**111 86 072**  
グラタン  
L-16 S-14.4 H-5.1  
¥2,100



**161 86 012**  
22cmパスタボウル  
D-22.4 H-3.7  
¥1,500



**113 86 044**  
28.5cmオーバルプラター  
L-29.1 S-22.5 H-4 ¥3,200



**113 86 071**  
27cmオーバルペーカ  
L-27 S-17.2 H-5.5 ¥3,200



**111 86 043**  
31.5cmプラター  
L-31.8 S-22 H-3.7 ¥4,600



**111 86 045**  
26cmプラター  
L-26.2 S-18.2 H-2.7 ¥2,900



**111 86 046**  
24cmプラター  
L-24 S-17 H-2.7 ¥2,100



**111 86 021**  
23cmボウル  
D-23.2 H-8.3  
¥2,600



**111 86 023**  
20cmボウル  
D-20 H-7  
¥2,400



**111 86 024**  
17cmボウル  
D-17 H-6.3  
¥1,400



**111 86 025**  
13.5cmボウル  
D-13.7 H-5.5  
¥900



**111 86 027**  
10cmボウル  
D-10.2 H-4.1  
¥750



**113 86 063**  
クリーマー  
L-10.7 S-8.1 H-8  
C-200cc ¥1,400



**113 86 051**  
ダイナーマグカップ  
L-12.2 S-8.8 H-9.3  
C-345cc ¥1,300



**113 86 052**  
ダイナーカップ  
L-11.4 S-8 H-8.6  
C-240cc ¥1,200



**113 86 053**  
ダイナーコーヒーカップ  
L-10.1 S-7.5 H-7.8  
C-200cc ¥1,100



**113 86 050**  
高台削りマグカップ  
L-12.2 S-8.8 H-10.4  
C-330cc ¥1,300



**111 86 052**  
コーヒーカップ  
L-10.5 S-7.8 H-7.3  
C-180cc ¥850



**111 86 053**  
ティーカップ  
L-12.5 S-9.9 H-5.8  
C-270cc ¥900



**113 86 056**  
ダイナースープカップ  
L-13.2 S-10.5 H-6.3  
C-340cc ¥1,500



**111 86 058**  
片手スープカップ  
L-15 S-12.1 H-6.4  
C-340cc ¥1,300

**161 86 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 86 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**161 86 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 86 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**111 86 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 86 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 86 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

COUNTRY SIDE  
CHARCOAL BROWN | チャコールブラウン



**111 61 002**  
26cmディナー皿  
D-26 H-3.2  
¥2,100

**111 61 004**  
23cmミート皿  
D-23.2 H-3  
¥1,500

**111 61 006**  
19.5cmケーキ皿  
D-19.8 H-2.9  
¥1,100

**111 61 008**  
15cmパン皿  
D-15 H-2.5  
¥850




**111 61 097**  
19cmラザニア  
L-19.7 S-12.2 H-3.5  
¥1,700



**111 61 072**  
グラタン  
L-16 S-14.4 H-5.1  
¥2,100



**161 61 012**  
22cmバスタボウル  
D-22.4 H-3.7  
¥1,500



COUNTRY SIDE



**113 61 044**  
28.5cmオーバルプラター  
L-29.1 S-22.5 H-4 ¥3,200



**113 61 071**  
27cmオーバルベーカー  
L-27 S-17.2 H-5.5 ¥3,200



**111 61 043**  
31.5cmプラター  
L-31.8 S-22 H-3.7 ¥4,600



**111 61 045**  
26cmプラター  
L-26.2 S-18.2 H-2.7 ¥2,900



**111 61 046**  
24cmプラター  
L-24 S-17 H-2.7 ¥2,100



**111 61 021**  
23cmボウル  
D-23.2 H-8.3  
¥2,600



**111 61 023**  
20cmボウル  
D-20 H-7  
¥2,400



**111 61 024**  
17cmボウル  
D-17 H-6.3  
¥1,400



**111 61 025**  
13.5cmボウル  
D-13.7 H-5.5  
¥900



**111 61 027**  
10cmボウル  
D-10.2 H-4.1  
¥750



**113 61 063**  
クリーマー  
L-10.7 S-8.1 H-8  
C-200cc ¥1,400



**113 61 051**  
ダイナーマグカップ  
L-12.2 S-8.8 H-9.3  
C-345cc ¥1,300



**113 61 052**  
ダイナーカップ  
L-11.4 S-8 H-8.6  
C-240cc ¥1,200



**113 61 053**  
ダイナーコーヒーカップ  
L-10.1 S-7.5 H-7.8  
C-200cc ¥1,100



**113 61 050**  
高台削りマグカップ  
L-12.2 S-8.8 H-10.4  
C-330cc ¥1,300



**111 61 052**  
コーヒーカップ  
L-10.5 S-7.8 H-7.3  
C-180cc ¥850



**111 61 053**  
ティーカップ  
L-12.5 S-9.9 H-5.8  
C-270cc ¥900



**113 61 056**  
ダイナースープカップ  
L-13.2 S-10.5 H-6.3  
C-340cc ¥1,500



**111 61 058**  
片手スープカップ  
L-15 S-12.1 H-6.4  
C-340cc ¥1,300

**161 61 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 61 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**161 61 055**  
モア兼用ソーサー  
D-15.3 H-2 ¥650

**111 61 056**  
コーヒーソーサー  
D-14.3 H-2.5 ¥650

**111 61 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 61 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700

**111 61 055**  
兼用ソーサー  
D-15.3 H-2.5 ¥700



COUNTRY SIDE  
OAK BROWN | オークブラウン



**134 64 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 64 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 64 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,200**



**134 64 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 64 008**  
16cmパン皿  
D-16 H-1.7 **¥850**



**134 64 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,500**



**134 64 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,200**



**134 64 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**

**134 64 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**



**134 64 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**

**134 64 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**



**134 64 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,200**

**161 64 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥750**

COUNTRY SIDE  
HONEY AMBER | ハニーアンバー



**134 63 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 63 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 63 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,200**



**134 63 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 63 008**  
16cmバン皿  
D-16 H-1.7 **¥850**



**134 63 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,500**



**134 63 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,200**



**134 63 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**



**134 63 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**



**134 63 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,200**

**134 63 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**

**134 63 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**

**161 63 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥750**

COUNTRY SIDE  
LAKE BLUE | レイクブルー



**134 87 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 87 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 87 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,200**



**134 87 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 87 008**  
16cmバン皿  
D-16 H-1.7 **¥850**



**134 87 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,500**



**134 87 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,200**



**134 87 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**



**134 87 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**



**134 87 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,200**

**134 87 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**

**134 87 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**

**161 87 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥750**



COUNTRY SIDE  
COUNTRY CREEK | カントリークリーク



**134 08 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 08 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 08 006**  
20cmケーキ皿  
D-21.3 H-2.2 **¥1,200**



**134 08 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**107 08 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,800**



**134 08 022**  
22cmスープパスタ  
D-22.3 H-5.2  
**¥1,800**



**134 08 023**  
19cmスープボウル  
D-19.2 H-4.4  
**¥1,500**



**134 08 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1  
**¥1,200**



**134 08 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9  
**¥4,800**



**134 08 044**  
29cmプラター  
L-29 S-20.1 H-3.6  
**¥3,700**



**134 08 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4  
**¥3,400**



**134 08 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**

**134 08 055**  
兼用ソーサー  
D-15.2 H-1.9  
**¥750**



**134 08 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**

**134 08 055**  
兼用ソーサー  
D-15.2 H-1.9  
**¥750**



COUNTRY SIDE  
 RASTIC TIMBER | ラスティックティンバー



**134 06 002**  
 27cmディナー皿  
 D-27.2 H-2.7 **¥2,500**



**134 06 004**  
 23cmミート皿  
 D-23.4 H-2.2 **¥1,500**



**134 06 006**  
 20cmケーキ皿  
 D-21.3 H-2.2 **¥1,200**



**134 06 007**  
 17.5cmケーキ皿  
 D-17.7 H-1.8 **¥950**



**107 06 012**  
 22.5cmパスタボウル  
 D-22.5 H-4.6 **¥1,800**



**134 06 022**  
 22cmスープパスタ  
 D-22.3 H-5.2 **¥1,800**



**134 06 023**  
 19cmスープボウル  
 D-19.2 H-4.4 **¥1,500**



**134 06 024**  
 15.5cmフルーツボウル  
 D-15.5 H-5.1 **¥1,200**



**134 06 042**  
 32.5cmプラター  
 L-32.6 S-22.8 H-3.9 **¥4,800**



**134 06 044**  
 29cmプラター  
 L-29 S-20.1 H-3.6 **¥3,700**



**134 06 045**  
 26.5cmプラター  
 L-26.5 S-18.2 H-3.4 **¥3,400**



**134 06 052**  
 コーヒーカップ  
 L-10.7 S-8.4 H-6.7  
 C-170cc **¥1,000**

**134 06 055**  
 兼用ソーサー  
 D-15.2 H-1.9 **¥750**



**134 06 053**  
 ティーカップ  
 L-11.8 S-9.5 H-6.1  
 C-225cc **¥1,000**

**134 06 055**  
 兼用ソーサー  
 D-15.2 H-1.9 **¥750**



COUNTRY SIDE  
RURAL LEAF | ルーラルリーフ



**134 07 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 07 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 07 006**  
20cmケーキ皿  
D-21.3 H-2.2 **¥1,200**



**134 07 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**107 07 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,800**



**134 07 022**  
22cmスープパスタ  
D-22.3 H-5.2 **¥1,800**



**134 07 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,500**



**134 07 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,200**



**134 07 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 **¥4,800**



**134 07 044**  
29cmプラター  
L-29 S-20.1 H-3.6 **¥3,700**



**134 07 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4 **¥3,400**



**134 07 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**

**134 07 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**



**134 07 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**

**134 07 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥750**



COUNTRY SIDE  
PROVINCE BRIGHT | プロビンスブライト



**134 04 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,500**



**134 04 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,500**



**134 04 006**  
20cmケーキ皿  
D-21.3 H-2.2 **¥1,200**



**134 04 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**107 04 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,800**



**134 04 022**  
22cmスープパスタ  
D-22.3 H-5.2  
**¥1,800**



**134 04 023**  
19cmスープボウル  
D-19.2 H-4.4  
**¥1,500**



**134 04 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1  
**¥1,200**



**134 04 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9  
**¥4,800**



**134 04 044**  
29cmプラター  
L-29 S-20.1 H-3.6  
**¥3,700**



**134 04 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4  
**¥3,400**



**134 04 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥1,000**

**134 04 055**  
兼用ソーサー  
D-15.2 H-1.9  
**¥750**



**134 04 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥1,000**

**134 04 055**  
兼用ソーサー  
D-15.2 H-1.9  
**¥750**



COUNTRY SIDE  
OCEAN BLUE | オーシャンブルー



**134 86 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,400**



**134 86 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,400**



**134 86 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,100**



**134 86 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 86 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 **¥4,700**



**107 86 012**  
22.5cmパスタボウル  
D-22.5 H-4.6  
**¥1,700**



**134 86 023**  
19cmスープボウル  
D-19.2 H-4.4  
**¥1,400**



**134 86 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1  
**¥1,100**



**134 86 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥950**



**134 86 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥950**



**134 86 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,100**

**134 86 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

**134 86 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

COUNTRY SIDE  
DESSERT BEIGE | デザートベージュ



**134 66 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,400**



**134 66 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,400**



**134 66 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,100**



**134 66 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 66 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 **¥4,700**



**107 66 012**  
22.5cmパスタボウル  
D-22.5 H-4.6  
**¥1,700**



**134 66 023**  
19cmスープボウル  
D-19.2 H-4.4  
**¥1,400**



**134 66 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1  
**¥1,100**



**134 66 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥950**



**134 66 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥950**



**134 66 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,100**

**134 66 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

**134 66 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

COUNTRY SIDE  
FOREST GREEN | フォレストグリーン



**134 78 002**  
27cmディナー皿  
D-27.2 H-2.7 **¥2,400**



**134 78 004**  
23cmミート皿  
D-23.4 H-2.2 **¥1,400**



**134 78 006**  
20cmケーキ皿  
D-19.8 H-2 **¥1,100**



**134 78 007**  
17.5cmケーキ皿  
D-17.7 H-1.8 **¥950**



**134 78 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 **¥4,700**



**107 78 012**  
22.5cmパスタボウル  
D-22.5 H-4.6  
**¥1,700**



**134 78 023**  
19cmスープボウル  
D-19.2 H-4.4  
**¥1,400**



**134 78 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1  
**¥1,100**



**134 78 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥950**



**134 78 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥950**



**134 78 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,100**

**134 78 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

**134 78 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥700**

COUNTRY SIDE  
DARK BROWN | ダーク ブラウン



**134 26 002**  
27cmディナー皿  
D-27.2 H-2.7  
¥2,200



**134 26 003**  
25.5cmディナー皿  
D-25.6 H-2.6  
¥2,000



**134 26 004**  
23cmミート皿  
D-23.4 H-2.2  
¥1,300



**134 26 005**  
21cmミート皿  
D-21.3 H-2.2  
¥1,100



**134 26 006**  
20cmケーキ皿  
D-19.8 H-2  
¥1,000



**134 26 007**  
17.5cmケーキ皿  
D-17.7 H-1.8  
¥850



**134 26 008**  
16cmパン皿  
D-16 H-1.7  
¥700



**134 26 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 ¥4,400



**134 26 044**  
29cmプラター  
L-29 S-20.1 H-3.6 ¥3,300



**134 26 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4 ¥2,900



**134 26 022**  
22cmスープパスタ  
D-22.3 H-5.2 **¥1,500**



**134 26 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,300**



**134 26 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,000**



**107 26 010**  
25.5cmパスタボウル  
D-25.5 H-5.1 **¥2,200**



**107 26 011**  
24cmパスタボウル  
D-24.1 H-4.9 **¥2,000**



**107 26 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,600**



**134 26 016**  
12.5cmディップ  
D-12.6 H-2.7 **¥850**



**134 26 086**  
オブロングラタン  
L-19.4 S-11.4 H-3.7 **¥1,800**



**134 26 056**  
片手スープカップ  
L-14 S-11.8 H-6.6  
C-350cc **¥1,500**



**134 26 054**  
両手スープカップ  
L-16.8 S-11.8 H-6.6  
C-350cc **¥1,600**



**134 26 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,100**



**134 26 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥900**



**134 26 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥900**

**161 26 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 26 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 26 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**134 26 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**

**134 26 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**



**134 26 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,000**



**134 26 060**  
シュガー  
D-8.3 H-9.3  
C-255cc **¥2,100**



**134 26 063**  
クリーマー  
L-11.1 S-6.3 H-7.6  
C-180cc **¥1,900**



**134 26 035**  
スタックスープボウル  
D-10.3 H-6.3  
C-260cc **¥900**



**134 26 098**  
7.5cmソースカップ  
D-7.6 H-4.4  
**¥700**



**134 26 099**  
6cmソースカップ  
D-6.2 H-3.6  
**¥600**

COUNTRY SIDE  
MOSS GREEN | モス グリーン



**134 27 002**  
27cmディナー皿  
D-27.2 H-2.7  
¥2,200



**134 27 003**  
25.5cmディナー皿  
D-25.6 H-2.6  
¥2,000



**134 27 004**  
23cmミート皿  
D-23.4 H-2.2  
¥1,300



**134 27 005**  
21cmミート皿  
D-21.3 H-2.2  
¥1,100



**134 27 006**  
20cmケーキ皿  
D-19.8 H-2  
¥1,000



**134 27 007**  
17.5cmケーキ皿  
D-17.7 H-1.8  
¥850



**134 27 008**  
16cmパン皿  
D-16 H-1.7  
¥700



**134 27 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 ¥4,400



**134 27 044**  
29cmプラター  
L-29 S-20.1 H-3.6 ¥3,300



**134 27 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4 ¥2,900



**134 27 022**  
22cmスープパスタ  
D-22.3 H-5.2 **¥1,500**



**134 27 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,300**



**134 27 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,000**



**107 27 010**  
25.5cmパスタボウル  
D-25.5 H-5.1 **¥2,200**



**107 27 011**  
24cmパスタボウル  
D-24.1 H-4.9 **¥2,000**



**107 27 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,600**



**134 27 016**  
12.5cmディップ  
D-12.6 H-2.7 **¥850**



**134 27 086**  
オブロングラタン  
L-19.4 S-11.4 H-3.7 **¥1,800**



**134 27 056**  
片手スープカップ  
L-14 S-11.8 H-6.6  
C-350cc **¥1,500**



**134 27 054**  
両手スープカップ  
L-16.8 S-11.8 H-6.6  
C-350cc **¥1,600**



**134 27 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,100**



**134 27 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥900**



**134 27 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥900**

**161 27 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 27 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 27 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**134 27 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**

**134 27 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**



**134 27 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,000**



**134 27 060**  
シュガー  
D-8.3 H-9.3  
C-255cc **¥2,100**



**134 27 063**  
クリーマー  
L-11.1 S-6.3 H-7.6  
C-180cc **¥1,900**



**134 27 035**  
スタックスープボウル  
D-10.3 H-6.3  
C-260cc **¥900**



**134 27 098**  
7.5cmソースカップ  
D-7.6 H-4.4 **¥700**



**134 27 099**  
6cmソースカップ  
D-6.2 H-3.6 **¥600**

COUNTRY SIDE  
NAVY BLUE | ネイビーブルー



**134 28 002**  
27cmディナー皿  
D-27.2 H-2.7  
¥2,200



**134 28 003**  
25.5cmディナー皿  
D-25.6 H-2.6  
¥2,000



**134 28 004**  
23cmミート皿  
D-23.4 H-2.2  
¥1,300



**134 28 005**  
21cmミート皿  
D-21.3 H-2.2  
¥1,100



**134 28 006**  
20cmケーキ皿  
D-19.8 H-2  
¥1,000



**134 28 007**  
17.5cmケーキ皿  
D-17.7 H-1.8  
¥850



**134 28 008**  
16cmパン皿  
D-16 H-1.7  
¥700



**134 28 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 ¥4,400



**134 28 044**  
29cmプラター  
L-29 S-20.1 H-3.6 ¥3,300



**134 28 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4 ¥2,900



**134 28 022**  
22cmスープパスタ  
D-22.3 H-5.2 **¥1,500**



**134 28 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,300**



**134 28 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,000**



**107 28 010**  
25.5cmパスタボウル  
D-25.5 H-5.1 **¥2,200**



**107 28 011**  
24cmパスタボウル  
D-24.1 H-4.9 **¥2,000**



**107 28 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,600**



**134 28 016**  
12.5cmディップ  
D-12.6 H-2.7 **¥850**



**134 28 086**  
オブロングラタン  
L-19.4 S-11.4 H-3.7 **¥1,800**



**134 28 056**  
片手スープカップ  
L-14 S-11.8 H-6.6  
C-350cc **¥1,500**



**134 28 054**  
両手スープカップ  
L-16.8 S-11.8 H-6.6  
C-350cc **¥1,600**



**134 28 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,100**



**134 28 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥900**



**134 28 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥900**

**161 28 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 28 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 28 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**134 28 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**

**134 28 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**



**134 28 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,000**



**134 28 060**  
シュガー  
D-8.3 H-9.3  
C-255cc **¥2,100**



**134 28 063**  
クリーマー  
L-11.1 S-6.3 H-7.6  
C-180cc **¥1,900**



**134 28 035**  
スタックスープボウル  
D-10.3 H-6.3  
C-260cc **¥900**



**134 28 098**  
7.5cmソースカップ  
D-7.6 H-4.4  
**¥700**



**134 28 099**  
6cmソースカップ  
D-6.2 H-3.6  
**¥600**

COUNTRY SIDE  
SOBER ORANGE | ソーバー オレンジ



**134 25 002**  
27cmディナー皿  
D-27.2 H-2.7  
¥2,200



**134 25 003**  
25.5cmディナー皿  
D-25.6 H-2.6  
¥2,000



**134 25 004**  
23cmミート皿  
D-23.4 H-2.2  
¥1,300



**134 25 005**  
21cmミート皿  
D-21.3 H-2.2  
¥1,100



**134 25 006**  
20cmケーキ皿  
D-19.8 H-2  
¥1,000



**134 25 007**  
17.5cmケーキ皿  
D-17.7 H-1.8  
¥850



**134 25 008**  
16cmパン皿  
D-16 H-1.7  
¥700



**134 25 042**  
32.5cmプラター  
L-32.6 S-22.8 H-3.9 ¥4,400



**134 25 044**  
29cmプラター  
L-29 S-20.1 H-3.6 ¥3,300



**134 25 045**  
26.5cmプラター  
L-26.5 S-18.2 H-3.4 ¥2,900



**134 25 022**  
22cmスープパスタ  
D-22.3 H-5.2 **¥1,500**



**134 25 023**  
19cmスープボウル  
D-19.2 H-4.4 **¥1,300**



**134 25 024**  
15.5cmフルーツボウル  
D-15.5 H-5.1 **¥1,000**



**107 25 010**  
25.5cmパスタボウル  
D-25.5 H-5.1 **¥2,200**



**107 25 011**  
24cmパスタボウル  
D-24.1 H-4.9 **¥2,000**



**107 25 012**  
22.5cmパスタボウル  
D-22.5 H-4.6 **¥1,600**



**134 25 016**  
12.5cmディップ  
D-12.6 H-2.7 **¥850**



**134 25 086**  
オブロングラタン  
L-19.4 S-11.4 H-3.7 **¥1,800**



**134 25 056**  
片手スープカップ  
L-14 S-11.8 H-6.6  
C-350cc **¥1,500**



**134 25 054**  
両手スープカップ  
L-16.8 S-11.8 H-6.6  
C-350cc **¥1,600**



**134 25 062**  
高台スタックコーヒーカップ  
L-10.9 S-8.3 H-6  
C-185cc **¥1,100**



**134 25 052**  
コーヒーカップ  
L-10.7 S-8.4 H-6.7  
C-170cc **¥900**



**134 25 053**  
ティーカップ  
L-11.8 S-9.5 H-6.1  
C-225cc **¥900**

**161 25 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 25 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**161 25 055**  
モア兼用ソーサー  
D-15.3 H-2.5 **¥650**

**134 25 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**

**134 25 055**  
兼用ソーサー  
D-15.2 H-1.9 **¥600**



**134 25 050**  
マグカップ  
L-11.3 S-8.8 H-9.2  
C-315cc **¥1,000**



**134 25 060**  
シュガー  
D-8.3 H-9.3  
C-255cc **¥2,100**



**134 25 063**  
クリーマー  
L-11.1 S-6.3 H-7.6  
C-180cc **¥1,900**



**134 25 035**  
スタックスープボウル  
D-10.3 H-6.3  
C-260cc **¥900**



**134 25 098**  
7.5cmソースカップ  
D-7.6 H-4.4  
**¥700**



**134 25 099**  
6cmソースカップ  
D-6.2 H-3.6  
**¥600**



COUNTRY SIDE  
BALSAMIC PURPLE | パルサミック パープル



**123 88 002**  
26cmプレート  
D-26 H-3 **¥2,300**



**123 88 004**  
23cmプレート  
D-23.3 H-2.6 **¥1,200**



**123 88 005**  
21cmプレート  
D-21 H-2.5 **¥1,100**



**123 88 006**  
19.5cmプレート  
D-19.6 H-2.3 **¥950**



**123 88 007**  
17cmプレート  
D-17 H-2.1 **¥850**



**123 88 008**  
15cmプレート  
D-15.1 H-1.9 **¥750**



**123 88 023**  
18.5cmボウル  
D-18.6 H-6.6 **¥2,000**



**123 88 024**  
16cmボウル  
D-16.1 H-5.7 **¥1,500**



**123 88 025**  
13.5cmボウル  
D-13.6 H-4.7 **¥1,100**



**144 88 077**  
9cmスタックボウル  
D-8.8 H-3.8 **¥900**



**144 88 078**  
6.5cmスタックボウル  
D-6.8 H-3.2 **¥850**



**127 88 050**  
スタックマグカップ  
L-11.1 S-8 H-8.8  
C-285cc **¥1,100**



**127 88 059**  
スタックコーヒーカップ  
L-12.1 S-9.3 H-6.3  
C-260cc **¥1,000**



**197 88 052** **197 88 055**  
コーヒーカップ コーヒーソーサー  
L-10.3 S-7.7 H-6.9 D-15 H-2  
C-175cc **¥950** **¥850**



COUNTRY SIDE  
ONIX BLUE | オニクス ブルー



**123 87 002**  
26cmプレート  
D-26 H-3 **¥2,300**



**123 87 004**  
23cmプレート  
D-23.3 H-2.6 **¥1,200**



**123 87 005**  
21cmプレート  
D-21 H-2.5 **¥1,100**



**123 87 006**  
19.5cmプレート  
D-19.6 H-2.3 **¥950**



**123 87 007**  
17cmプレート  
D-17 H-2.1 **¥850**



**123 87 008**  
15cmプレート  
D-15.1 H-1.9 **¥750**



**123 87 023**  
18.5cmボウル  
D-18.6 H-6.6 **¥2,000**



**123 87 024**  
16cmボウル  
D-16.1 H-5.7 **¥1,500**



**123 87 025**  
13.5cmボウル  
D-13.6 H-4.7 **¥1,100**



**144 87 077**  
9cmスタックボウル  
D-8.8 H-3.8 **¥900**



**144 87 078**  
6.5cmスタックボウル  
D-6.8 H-3.2 **¥850**



**127 87 050**  
スタックマグカップ  
L-11.1 S-8 H-8.8  
C-285cc **¥1,100**



**127 87 059**  
スタックコーヒーカップ  
L-12.1 S-9.3 H-6.3  
C-260cc **¥1,000**



**197 87 052**  
コーヒーカップ  
L-10.3 S-7.7 H-6.9  
C-175cc **¥950**

**197 87 055**  
コーヒーソーサー  
D-15 H-2  
**¥850**



COUNTRY SIDE  
DOVE GRAY | ダブ グレー



**123 21 002**  
26cmプレート  
D-26 H-3 **¥2,300**



**123 21 004**  
23cmプレート  
D-23.3 H-2.6 **¥1,200**



**123 21 005**  
21cmプレート  
D-21 H-2.5 **¥1,100**



**123 21 006**  
19.5cmプレート  
D-19.6 H-2.3 **¥950**



**123 21 007**  
17cmプレート  
D-17 H-2.1 **¥850**



**123 21 008**  
15cmプレート  
D-15.1 H-1.9 **¥750**



**123 21 023**  
18.5cmボウル  
D-18.6 H-6.6 **¥2,000**



**123 21 024**  
16cmボウル  
D-16.1 H-5.7 **¥1,500**



**123 21 025**  
13.5cmボウル  
D-13.6 H-4.7 **¥1,100**



**144 21 077**  
9cmスタックボウル  
D-8.8 H-3.8 **¥900**



**144 21 078**  
6.5cmスタックボウル  
D-6.8 H-3.2 **¥850**



**127 21 050**  
スタックマグカップ  
L-11.1 S-8 H-8.8  
C-285cc **¥1,100**



**127 21 059**  
スタックコーヒーカップ  
L-12.1 S-9.3 H-6.3  
C-260cc **¥1,000**



**197 21 052**  
コーヒーカップ  
L-10.3 S-7.7 H-6.9  
C-175cc **¥950**

**197 21 055**  
コーヒーソーサー  
D-15 H-2 **¥850**



COUNTRY SIDE  
CILANTRO GREEN | シラントロ グリーン



**123 73 002**  
26cmプレート  
D-26 H-3 **¥2,300**



**123 73 004**  
23cmプレート  
D-23.3 H-2.6 **¥1,200**



**123 73 005**  
21cmプレート  
D-21 H-2.5 **¥1,100**



**123 73 006**  
19.5cmプレート  
D-19.6 H-2.3 **¥950**



**123 73 007**  
17cmプレート  
D-17 H-2.1 **¥850**



**123 73 008**  
15cmプレート  
D-15.1 H-1.9 **¥750**



**123 73 023**  
18.5cmボウル  
D-18.6 H-6.6 **¥2,000**



**123 73 024**  
16cmボウル  
D-16.1 H-5.7 **¥1,500**



**123 73 025**  
13.5cmボウル  
D-13.6 H-4.7 **¥1,100**



**144 73 077**  
9cmスタックボウル  
D-8.8 H-3.8 **¥900**



**144 73 078**  
6.5cmスタックボウル  
D-6.8 H-3.2 **¥850**



**127 73 050**  
スタックマグカップ  
L-11.1 S-8 H-8.8  
C-285cc **¥1,100**



**127 73 059**  
スタックコーヒーカップ  
L-12.1 S-9.3 H-6.3  
C-260cc **¥1,000**



**197 73 052**  
コーヒーカップ  
L-10.3 S-7.7 H-6.9  
C-175cc **¥950**

**197 73 055**  
コーヒーソーサー  
D-15 H-2  
**¥850**



**132 22 001**  
31.5cm大皿  
D-31.5 H-3.4 ¥4,500



**132 22 002**  
27.5cmディナー皿  
D-27.5 H-3.2 ¥2,400



**132 22 004**  
23cmミート皿  
D-23 H-3 ¥1,600



**132 22 006**  
19.5cmケーキ皿  
D-19.5 H-2.5 ¥1,400



**132 22 008**  
15.5cmパン皿  
D-15.5 H-2.2 ¥950



**132 22 012**  
22.5cm  
カレースパゲティボウル  
D-22.7 H-3.8 ¥1,600



**132 22 025**  
12.5cmスモールボウル  
D-12.8 H-5.5  
¥1,200



**132 22 052**  
コーヒーカップ  
L-10.4 S-8 H-7.5  
C-200cc ¥1,000

**132 22 056**  
コーヒーソーサー  
D-15 H-2 ¥850



**132 26 001**  
31.5cm大皿  
D-31.5 H-3.4 **¥4,500**



**132 26 002**  
27.5cmディナー皿  
D-27.5 H-3.2 **¥2,400**



**132 26 004**  
23cmミート皿  
D-23 H-3 **¥1,600**



**132 26 006**  
19.5cmケーキ皿  
D-19.5 H-2.5 **¥1,400**



**132 26 008**  
15.5cmパン皿  
D-15.5 H-2.2 **¥950**



**132 26 012**  
22.5cm  
カレースパゲティボウル  
D-22.7 H-3.8 **¥1,600**



**132 26 025**  
12.5cmスモールボウル  
D-12.8 H-5.5 **¥1,200**



**132 26 052**  
コーヒーカップ  
L-10.4 S-8 H-7.5  
C-200cc **¥1,000**

**132 26 056**  
コーヒーソーサー  
D-15 H-2 **¥850**



**132 25 001**  
31.5cm大皿  
D-31.5 H-3.4 **¥4,500**



**132 25 002**  
27.5cmディナー皿  
D-27.5 H-3.2 **¥2,400**



**132 25 004**  
23cmミート皿  
D-23 H-3 **¥1,600**



**132 25 006**  
19.5cmケーキ皿  
D-19.5 H-2.5 **¥1,400**



**132 25 008**  
15.5cmパン皿  
D-15.5 H-2.2 **¥950**



**132 25 012**  
22.5cmカレースパゲティボウル  
D-22.7 H-3.8 **¥1,600**



**132 25 025**  
12.5cmスモールボウル  
D-12.8 H-5.5 **¥1,200**



**132 25 052**  
コーヒーカップ  
L-10.4 S-8 H-7.5  
C-200cc **¥1,000**

**132 25 056**  
コーヒーソーサー  
D-15 H-2 **¥850**



**132 27 001**  
31.5cm大皿  
D-31.5 H-3.4 **¥4,500**



**132 27 002**  
27.5cmディナー皿  
D-27.5 H-3.2 **¥2,400**



**132 27 004**  
23cmミート皿  
D-23 H-3 **¥1,600**



**132 27 006**  
19.5cmケーキ皿  
D-19.5 H-2.5 **¥1,400**



**132 27 008**  
15.5cmパン皿  
D-15.5 H-2.2 **¥950**



**132 27 012**  
22.5cmカレースパゲティボウル  
D-22.7 H-3.8 **¥1,600**



**132 27 025**  
12.5cmスモールボウル  
D-12.8 H-5.5 **¥1,200**



**132 27 052**  
コーヒーカップ  
L-10.4 S-8 H-7.5  
C-200cc **¥1,000**

**132 27 056**  
コーヒーソーサー  
D-15 H-2 **¥850**



**131 21 001**  
31.5cm大皿  
D-31.5 H-3  
¥4,500

**131 21 002**  
27cmディナー皿  
D-27 H-2.4  
¥2,400

**131 21 004**  
23cmミート皿  
D-23.3 H-2  
¥1,600

**131 21 006**  
19.5cmケーキ皿  
D-19.5 H-1.8  
¥1,400

**131 21 007**  
17.5cmパン皿  
D-17.5 H-1.8  
¥1,100

**131 21 008**  
15.5cmパン皿  
D-15.5 H-1.5  
¥950



**131 21 010**  
25.5cmカレースパゲティボウル  
D-25.5 H-4 ¥2,200



**131 21 013**  
19cmスープボウル  
D-19 H-4 ¥1,300



**131 21 034**  
16cmオートミール  
D-16.2 H-4.8 ¥1,200



**131 21 014**  
15.5cmフルーツボウル  
D-15.7 H-3.4 ¥1,100



**131 21 052**  
コーヒーカップ  
L-10.3 S-7.8 H-6.7  
C-200cc ¥1,000

**131 21 055**  
兼用ソーサー  
D-15 H-2.1  
¥850



**131 21 053**  
ティーカップ  
L-11.8 S-9.2 H-5.4  
C-200cc ¥1,000

**131 21 055**  
兼用ソーサー  
D-15 H-2.1  
¥850



**128 27 001**  
32cmピザスバゲティ皿  
D-32.3 H-3.2 ¥4,500



**128 27 002**  
28cmピザスバゲティ皿  
D-28 H-2.8 ¥2,400



**128 27 004**  
23cmミート皿  
D-23.2 H-2.5 ¥1,600



**128 27 006**  
19cmケーキ皿  
D-19.3 H-2 ¥1,400



**128 27 015**  
24cmスープバゲティボウル  
D-24 H-6 ¥2,200



**128 27 012**  
22cmカレースバゲティボウル  
D-22 H-3.5 ¥1,800



**128 27 025**  
14cmスモールサラダボウル  
D-14 H-4.5 ¥1,200



**128 28 001**  
32cmピザスバゲティ皿  
D-32.3 H-3.2 ¥4,500



**128 28 002**  
28cmピザスバゲティ皿  
D-28 H-2.8 ¥2,400



**128 28 004**  
23cmミート皿  
D-23.2 H-2.5 ¥1,600



**128 28 006**  
19cmケーキ皿  
D-19.3 H-2 ¥1,400



**128 28 015**  
24cmスープバゲティボウル  
D-24 H-6 ¥2,200



**128 28 012**  
22cmカレースバゲティボウル  
D-22 H-3.5 ¥1,800



**128 28 025**  
14cmスモールサラダボウル  
D-14 H-4.5 ¥1,200



**131 07 001**  
31.5cm大皿  
D-31.5 H-3 **¥4,500**



**131 07 002**  
27cmディナー皿  
D-27 H-2.4 **¥2,400**



**131 07 004**  
23cmミート皿  
D-23.3 H-2 **¥1,600**



**131 07 006**  
19.5cmケーキ皿  
D-19.5 H-1.8 **¥1,400**



**131 07 007**  
17.5cmパン皿  
D-17.5 H-1.8 **¥1,100**



**131 07 008**  
15.5cmパン皿  
D-15.5 H-1.5 **¥950**



**131 07 034**  
16cmオートミール  
D-16.2 H-4.8 **¥1,200**



**131 07 010**  
25.5cmカレースパゲティボウル  
D-25.5 H-4 **¥2,200**



**131 07 013**  
19cmスープボウル  
D-19 H-4 **¥1,300**



**131 07 014**  
15.5cmフルーツボウル  
D-15.7 H-3.4 **¥1,100**



**131 07 052**  
コーヒーカップ  
L-10.3 S-7.8 H-6.7  
C-200cc **¥1,000**  
**131 07 055**  
兼用ソーサー  
D-15 H-2.1 **¥850**



**131 07 053**  
ティーカップ  
L-11.8 S-9.2 H-5.4  
C-200cc **¥1,000**  
**131 07 055**  
兼用ソーサー  
D-15 H-2.1 **¥850**

# JADE ROAD ジェイド ロード

ニューボン



**131 72 002**  
27cmディナー皿  
D-27 H-2.4 **¥2,400**



**131 72 004**  
23cmミート皿  
D-23.3 H-2 **¥1,600**



**131 72 006**  
19.5cmケーキ皿  
D-19.5 H-1.8 **¥1,400**



**131 72 007**  
17.5cmパン皿  
D-17.5 H-1.8 **¥1,100**



**131 72 008**  
15.5cmパン皿  
D-15.5 H-1.5 **¥950**



**131 72 034**  
16cmオートミール  
D-16.2 H-4.8 **¥1,200**



**131 72 010**  
25.5cmカレースバゲティボウル  
D-25.5 H-4 **¥2,200**



**131 72 013**  
19cmスープボウル  
D-19 H-4 **¥1,300**



**131 72 014**  
15.5cmフルーツボウル  
D-15.7 H-3.4 **¥1,100**



**131 72 052**  
コーヒーカップ  
L-10.3 S-7.8 H-6.7  
C-200cc **¥1,000**  
**131 72 055**  
兼用ソーサー  
D-15 H-2.1 **¥850**



**131 72 053**  
ティーカップ  
L-11.8 S-9.2 H-5.4  
C-200cc **¥1,000**  
**131 72 055**  
兼用ソーサー  
D-15 H-2.1 **¥850**



**131 52 001**  
31.5cm大皿  
D-31.5 H-3 ¥4,500



**131 52 002**  
27cmディナー皿  
D-27 H-2.4 ¥2,400



**131 52 004**  
23cmミート皿  
D-23.3 H-2 ¥1,600



**131 52 006**  
19.5cmケーキ皿  
D-19.5 H-1.8 ¥1,400



**131 52 007**  
17.5cmパン皿  
D-17.5 H-1.8 ¥1,100



**131 52 008**  
15.5cmパン皿  
D-15.5 H-1.5 ¥950



**131 52 034**  
16cmオートミール  
D-16.2 H-4.8 ¥1,200



**131 52 010**  
25.5cmカレースパゲティボウル  
D-25.5 H-4 ¥2,200



**131 52 013**  
19cmスープボウル  
D-19 H-4 ¥1,300



**131 52 014**  
15.5cmフルーツボウル  
D-15.7 H-3.4 ¥1,100



**131 52 052**  
コーヒーカップ  
L-10.3 S-7.8 H-6.7  
C-200cc ¥1,000  
**131 52 055**  
兼用ソーサー  
D-15 H-2.1 ¥850



**131 52 053**  
ティーカップ  
L-11.8 S-9.2 H-5.4  
C-200cc ¥1,000  
**131 52 055**  
兼用ソーサー  
D-15 H-2.1 ¥850

# CLAIR クレール

デュラミックス強化白磁 オープン可 スタック可<直火不可>



**234 00 075**  
18cmキャセロール  
L-18.3 S-15 H-4.6  
¥2,300  
(A34 00 004対応)



**234 00 076**  
16.5cmキャセロール  
L-16.5 S-13.5 H-4.2  
¥1,900  
(A34 00 005対応)



**234 00 077**  
14.5cmキャセロール  
L-14.6 S-12 H-3.8  
¥1,500



**234 00 070**  
19cmグラタン  
L-19 S-15.8 H-3.7  
¥2,000  
(A34 00 004対応)



**234 00 071**  
16cmグラタン  
L-16.4 S-13.5 H-3.5  
¥1,800  
(A34 00 005対応)



**234 00 072**  
13.5cmグラタン  
L-13.7 S-11.2 H-3  
¥1,500



**234 00 060**  
27cm手付楕円浅グラタン  
L-27.2 S-16.5 H-4.4  
¥3,500



**234 00 062**  
22cm手付楕円浅グラタン  
L-22.3 S-13.7 H-3.6  
¥2,300  
(A34 00 002対応)



**234 00 063**  
20.5cm手付楕円浅グラタン  
L-20.6 S-12.4 H-3.2  
¥2,000  
(A34 00 003対応)



**234 00 065**  
20cm楕円グラタン  
L-20 S-13.6 H-4.7  
¥2,100  
(A34 00 002対応)



**234 00 066**  
18.5cm楕円グラタン  
L-18.5 S-12.4 H-4.2  
¥2,000  
(A34 00 003対応)



**234 00 088**  
トールスフレ  
D-6.2 H-5  
¥650



**234 00 089**  
トールスフレ  
D-6.2 H-3.8  
¥600



**293 00 080**  
8.5cmスタックスフレ  
D-8.5 H-4  
¥650



**293 00 081**  
7.5cmスタックスフレ  
D-7.9 H-3.7  
¥600



**293 00 082**  
7cmスタックスフレ  
D-7.3 H-3.3  
¥550



**293 00 083**  
6.5cmスタックスフレ  
D-6.6 H-3  
¥500



**293 00 084**  
5.5cmスタックスフレ  
D-5.7 H-2.5  
¥450



**234 00 096**  
13cmタルト  
D-13.1 H-3.2 ¥950



**234 00 097**  
11.5cmタルト  
D-11.6 H-3 ¥750



**234 00 098**  
10cmタルト  
D-10 H-2.7 ¥700



**234 00 099**  
8.5cmタルト  
D-8.6 H-2.6 ¥600



**A34 00 004**  
丸受台 M [TH]  
L-22 S-17.7 H-1.8(内寸12.5)  
¥2,900  
材質:ラバーウッド



**A34 00 005**  
丸受台 S [TH]  
L-19 S-15.5 H-1.8(内寸10.5)  
¥2,700  
材質:ラバーウッド

# フォルノ FORNO

デュラミックス強化白磁 オープン可 スタック可<直火不可>

CLAIR / FORNO



**234 05 075**  
18cmキャセロール  
L-18.3 S-15 H-4.6  
¥2,900  
(A34 00 004対応)



**234 05 076**  
16.5cmキャセロール  
L-16.5 S-13.5 H-4.2  
¥2,200  
(A34 00 005対応)



**234 05 077**  
14.5cmキャセロール  
L-14.6 S-12 H-3.8  
¥1,800



**234 05 070**  
19cmグラタン  
L-19 S-15.8 H-3.7  
¥2,300  
(A34 00 004対応)



**234 05 071**  
16cmグラタン  
L-16.4 S-13.5 H-3.5  
¥2,100  
(A34 00 005対応)



**234 05 072**  
13.5cmグラタン  
L-13.7 S-11.2 H-3  
¥1,800



**234 05 060**  
27cm手付楕円浅グラタン  
L-27.2 S-16.5 H-4.4  
¥4,100



**234 05 062**  
22cm手付楕円浅グラタン  
L-22.3 S-13.7 H-3.6  
¥2,900  
(A34 00 002対応)



**234 05 063**  
20.5cm手付楕円浅グラタン  
L-20.6 S-12.4 H-3.2  
¥2,300  
(A34 00 003対応)



**234 05 065**  
20cm楕円グラタン  
L-20 S-13.6 H-4.7  
¥2,500  
(A34 00 002対応)



**234 05 066**  
18.5cm楕円グラタン  
L-18.5 S-12.4 H-4.2  
¥2,300  
(A34 00 003対応)



**234 05 088**  
トールスフレ  
D-6.2 H-5  
¥750



**234 05 089**  
トールスフレ  
D-6.2 H-3.8  
¥700



**293 05 080**  
8.5cmスタックスフレ  
D-8.5 H-4  
¥850



**293 05 081**  
7.5cmスタックスフレ  
D-7.9 H-3.7  
¥700



**293 05 082**  
7cmスタックスフレ  
D-7.3 H-3.3  
¥650



**293 05 083**  
6.5cmスタックスフレ  
D-6.6 H-3  
¥600



**293 05 084**  
5.5cmスタックスフレ  
D-5.7 H-2.5  
¥550



**234 05 096**  
13cmタルト  
D-13.1 H-3.2 ¥1,100



**234 05 097**  
11.5cmタルト  
D-11.6 H-3 ¥950



**234 05 098**  
10cmタルト  
D-10 H-2.7 ¥850



**234 05 099**  
8.5cmタルト  
D-8.6 H-2.6 ¥700



**A34 00 002**  
楕円受台 M [TH]  
L-26.5 S-17 H-1.8(内寸18.5×12.5)  
¥3,200  
材質:アカシア



**A34 00 003**  
楕円受台 S [TH]  
L-24 S-14.2 H-1.8(内寸15.5×9.5)  
¥2,800  
材質:アカシア



**193 25 081**  
 7.5cmスタックボウル  
 D-7.9 H-3.7 ¥650



**193 25 082**  
 7cmスタックボウル  
 D-7.3 H-3.3 ¥600

**193 25 083**  
 6.5cmスタックボウル  
 D-6.6 H-3 ¥550



**193 25 096**  
 15cmタルト  
 D-15.2 H-3.3 ¥1,300

**193 25 098**  
 10cmタルト  
 D-10.3 H-2.9 ¥750

**193 25 097**  
 12.5cmタルト  
 D-12.6 H-3.1 ¥900

**193 25 099**  
 8cmタルト  
 D-8.2 H-2.6 ¥700



**193 25 086**  
 13cmスフレ  
 D-13 H-6.2 C-500cc ¥1,400

**193 25 087**  
 11cmスフレ  
 D-11.2 H-5.6 C-330cc ¥1,100



**193 25 088**  
 9.5cmスフレ  
 D-9.7 H-4.7 C-220cc ¥750

**193 25 089**  
 8cmスフレ  
 D-8.2 H-4.3 C-130cc ¥600



**193 25 084**  
 17.5cm楕円タルト  
 L-17.5 S-13 H-4.1 ¥1,800

**193 25 085**  
 11.5cm楕円タルト  
 L-11.9 S-9.1 H-2.8 ¥1,200



**193 25 077**  
 20cm舟型グラタン  
 L-20.3 S-13.4 H-4 ¥1,900

**193 25 078**  
 15cm舟型グラタン  
 L-15.4 S-10.3 H-3.4 ¥1,500



**193 25 076**  
 19cm舟型オープンパン  
 L-19 S-13 H-3.8 ¥1,900



**193 25 054**  
 22cm浅オープンパン  
 L-22.1 S-19 H-4.3 ¥2,300

**193 25 055**  
 19.5cm浅オープンパン  
 L-19.5 S-16.6 H-4 ¥1,900



**193 25 079**  
 オニオンスープ  
 L-13.7 S-11.7 H-5.8 ¥1,600



**193 25 070**  
 16cmグラタン  
 L-16.2 S-15.1 H-5 ¥1,800



**193 25 073**  
 18.5cmシチュー  
 L-18.9 S-17 H-4.2 ¥2,000



**193 25 093**  
 8cmハートココット  
 D-8 H-3.6 ¥900



**193 25 094**  
 7cmハートココット  
 D-7 H-3.2 ¥850



**193 20 081**  
7.5cmスタックボウル  
D-7.9 H-3.7 ¥550



**193 20 082**  
7cmスタックボウル  
D-7.3 H-3.3 ¥500

**193 20 083**  
6.5cmスタックボウル  
D-6.6 H-3 ¥400



**131 20 096**  
15cmタルト  
D-15.2 H-3.3 ¥1,100

**131 20 098**  
10cmタルト  
D-10.3 H-2.9 ¥650

**131 20 097**  
12.5cmタルト  
D-12.6 H-3.1 ¥700

**131 20 099**  
8cmタルト  
D-8.2 H-2.6 ¥600



**131 20 086**  
13cmスフレ  
D-13 H-6.2 C-500cc ¥1,100

**131 20 087**  
11cmスフレ  
D-11.2 H-5.6 C-330cc ¥850



**131 20 088**  
9.5cmスフレ  
D-9.7 H-4.7 C-220cc ¥600

**131 20 089**  
8cmスフレ  
D-8.2 H-4.3 C-130cc ¥500



**193 20 084**  
17.5cm楕円タルト  
L-17.5 S-13 H-4.1 ¥1,600

**193 20 085**  
11.5cm楕円タルト  
L-11.9 S-9.1 H-2.8 ¥1,100



**122 20 076**  
20cm舟型グラタン  
L-20.3 S-13.4 H-4 ¥1,600

**122 20 077**  
15cm舟型グラタン  
L-15.4 S-10.3 H-3.4 ¥1,400



**131 20 076**  
19cm舟型オープンパン  
L-19 S-13 H-3.8 ¥1,600



**193 20 054**  
22cm浅オープンパン  
L-22.1 S-19 H-4.3 ¥2,100

**132 20 074**  
19cm浅オープンパン  
L-19.4 S-16.5 H-3.9 ¥1,800



**193 20 079**  
オニオンスープ  
L-13.7 S-11.7 H-5.8 ¥1,500



**121 20 072**  
16cmグラタン  
L-16.2 S-15 H-5 ¥1,600



**121 20 073**  
18.5cmシチュー  
L-18.7 S-16.8 H-3.7 ¥1,800



**193 20 093**  
8cmハートココット  
D-8 H-3.6 ¥700



**193 20 094**  
7cmハートココット  
D-7 H-3.2 ¥650

